



PISO-P32C32U(-5V)/ PEX-P32C32 Quick Start

v1.4, Dec. 2018

What's in the box?

The package includes the following items:

PISO-P32C32U(-5V)



or

PEX-P32C32



PISO/PEX-P32C32 Card x 1



Quick Start x 1 (This Document)



CA-4037B Cable x 1



CA-4002 D-Sub Connector x 2


Related Information

- For more detailed information related to the user manual and software for UniDAQ Driver & SDK:
<http://ftp.icpdas.com/pub/cd/iocard/pci/napdos/pci/unidaq/>
- For more detailed information related to the hardware settings for PISO/PEX-P32C32 Series Card:
<http://ftp.icpdas.com/pub/cd/iocard/pci/napdos/pci/piso-dio/manual/>
- DN-37 and CA-3710 Cable Page (optional):
http://www.icpdas.com/products/DAQ/screw_terminal/dn_37.htm
http://www.icpdas.com/root/product/solutions/accessories/cable/cable_selection.html

1 Appearance

LED1: DO indicator
LED2: DI indicator

LED3: DO indicator
LED4: DI indicator



2 Jumper Settings


Jumpers JP1 and JP2

Jumpers JP1 and JP2 are used to specify whether the Digital Input is either Internal or External Power. **NOTE: Ensure that Jumpers JP1 and JP2 are in the default positions before performing a self-test.**

<input checked="" type="checkbox"/> External Power (Default)	Internal Power
<p>EXT</p>	<p>INT</p>

3 Installing a PISO/PEX-P32C32

- 1) Power off the PC.
- 2) Remove all covers from the Computer.
- 3) Carefully insert the PISO/PEX-P32C32 Series Card into PCI/PCIe slot.
- 4) Replace the PC Covers.
- 5) Power on the PC.
- 6) Download or locate the Windows driver.




The **UniDAQ driver** supports 32-/64-bit Windows XP/2003/2008/7/8/10. It is recommended that new users install this driver, which can be found in the <http://ftp.icpdas.com/pub/cd/iocard/pci/napdos/pci/unidaq/dll/driver/>

The **PISO-DIO Series classic driver** supports Windows 98/NT/2K and 32-bit XP/2003/2008/7/8/10. Recommended to install this driver for have been used PISO-P32C32 Series card of regular user, refer to: <http://ftp.icpdas.com/pub/cd/iocard/pci/napdos/pci/piso-dio/manual/quickstart/classic/>


7) Setup the UniDAQ Driver DLL, click the “**Next>**” button for all dialogs. **NOTE:** For more detailed information related to driver installation, refer to Chapter 2 “Starting” in the UniDAQ SDK user manual.

8) The operating system will automatically detect the new hardware and install the necessary drivers after reboot the PC.

9) Open the “**Device Manager**” to verify that the PISO/PEX-P32C32 Series Card has been correctly installed and is in the Device Manager, as illustrated on right.



4 Pin Assignments



Extension Cable (CA-4037B):
DB-40-Pin conversion DB-37-Pin



NOTES:

1. **Ext.GND:** External Power Ground
2. **Ext.PWR:** External Power Input
3. **N.C.:** None Connect
4. For detailed information about the **DI and DO wiring note**, refer to **Section 2.3 “Isolated DI Architecture”** and **Section 2.4 “Isolated DO Architecture”** in the PISO-P32C32 Series user manual.

5

Wiring the DI and DO for Self-test

- 1) Verify that Jumpers **JP1** and **JP2** on the PISO/PEX-P32C32 Series Card are set to the “**External Power (default)**” position. Refer to **Chapter 2 “Jumper Settings”** above (**P2**).
- 2) Connect the DN-37 to CON1 on the PISO/PEX-P32C32 Series Card using the CA-3710 cable.
- 3) Connect the **DI <0-15>** (Pin2 - Pin17) with **DO <0-15>** (Pin21 – Pin36).
i.e., DI0(Pin2) with DO0(Pin21) ... DI15(Pin17) with DO15(Pin36).

➤ The External Power Wiring for PEX-P32C32/PISO-P32C32U:

- 4) Connect the **External Power Supply +9V ~ +24 V** to **COM1A** (Pin18) and **Ext.PWR0** (Pin37), see Figure 1-1.
- 5) Connect the **External Power Supply GND** to **COM1B** (Pin19) and **Ext.GND0** (Pin1/Pin20), see Figure 1-1.


NOTE: The PEX-P32C32/PISO-P32C32U suggests input voltage range +9 to +24 V (Logic high). (Higher voltage over the limitation will cause the hardware damage.)

➤ The External Power Wiring for PISO-P32C32U-5V:


- 4) Connect the **External Power Supply +5V ~ +12 V** to **COM1A** (Pin18) and **Ext.PWR0** (Pin37), see Figure 1-2.
- 5) Connect the **External Power Supply GND** to **COM1B** (Pin19) and **Ext.GND0** (Pin1/Pin20), see Figure 1-2.

NOTE: The PISO-P32C32U-5V suggests input voltage range +5 to +12V (Logic high). (Higher voltage over the limitation will cause the hardware damage.)

➤ **Figure 1-1: The PEX-P32C32/PISO-P32C32U wiring:**




➤ **Figure 1-2: The PISO-P32C32U-5V wiring:**




6 Testing your PISO/PEX-P32C32


- 1) Launch the **UniDAQ Utility** software. The UniDAQ Utility will be placed in the **default path “C:\ICPDAS\UniDAQ\Driver”** after completing installation.



- 2) Confirm that PISO-P32C32 Series Card has been successfully installed in the Host system. **Note that the device numbers start from 0.**
- 3) Click the “**TEST**” button to start the test.




- 4) Click the “**Digital Output**” tab.
- 5) Select “**Port0**” from the “**Port Number**” drop-down menu.
- 6) Click the **DO channels 0, 2, 4 and 6** buttons.



Port0: DO0-7
 Port1: DO8-15
 Port2: N.C.
 Port3: N.C.

- 7) Click the “**Digital Input**” tab.
- 8) Select “**Port0**” from the “**Port Number**” drop-down menu.
- 9) The DI indicators will turn **black** when the corresponding **DO channels 0, 2, 4 and 6** are high.

NOTE: Port0/1 DI is the reverse logic, so the red light means low status (Logic 0) and the black light means high status (Logic 1).



Port0: DI0-7
 Port1: DI8-15
 Port2: N.C.
 Port3: N.C.