



---

# Modbus Utility User Manual

---

September 2014

Version 1.0.3

# Table of Contents

<b>1.</b>	<b>Introduction.....</b>	<b>6</b>
1.1.	Introduction to the User Manual.....	6
1.2.	Modbus Protocol.....	7
1.2.1.	What is the Modbus protocol? .....	7
1.2.2.	What is the Modbus/TCP protocol? .....	7
1.2.3.	What software supports the Modbus and Modbus/TCP protocol? .....	7
1.2.4.	What are the benefits of using Modbus and Modbus/TCP? .....	7
1.2.5.	Modbus Resources.....	7
1.3.	Default Firmware Features .....	8
1.3.1.	Support for the Modbus/TCP communication protocol that allows access to I/O devices inserted in the I/O slots.....	8
1.3.2.	Support for the VxComm technique for all COM ports on connected controllers .....	8
1.3.3.	Automatic I/O module scanning .....	8
1.3.4.	Automatic assignment of a register address for the I/O modules .....	9
1.3.5.	Allows simultaneous access by multiple clients (or masters) .....	9
1.3.6.	Online configuration via Ethernet using the Modbus Utility.....	9
1.3.7.	Supports I-8000 and I-87000 series I/O modules .....	9
1.3.8.	Updateable and programmable firmware .....	9
1.4.	Typical Applications .....	10
1.4.1.	Basic Application 1: Modbus TCP I/O Device.....	10
1.4.2.	Basic Application 2: Modbus/RTU to Modbus/TCP Converter .....	11

1.4.3.	Basic Application 3: Modbus/TCP I/O Device using the VxComm Technique.....	12
1.4.4.	Advanced Application 1: User-defined Modbus/TCP Controller.....	13
1.4.5.	Advanced Application 2: Modbus/TCP Controller using the VxComm Technique.....	13
1.5.	Supported Modules .....	13
<b>2.</b>	<b>Starting the Modbus Utility .....</b>	<b>14</b>
2.1.	Introduction to the User Interface.....	15
2.2.	Updating the Firmware .....	17
2.2.1.	Updating via Ethernet .....	17
2.2.2.	Updating via a Serial Port.....	20
2.3.	Network Settings.....	23
2.3.1.	Method 1: Under Running Firmware Mode .....	23
2.3.2.	Method 2: While Operating in INIT Mode .....	26
2.4.	Net ID (Station Number) Settings .....	28
2.5.	Connecting to the Controller .....	29
2.5.1.	Connecting via the Ethernet (Modbus/TCP).....	29
2.5.2.	Connecting via a Serial Port (Modbus/RTU) .....	30
2.5.3.	Refreshing the Configuration after Connecting.....	31
2.6.	Address Table (Mapping Table) .....	32
2.7.	Library Version .....	33
2.8.	Analog Module Range Code and Offset Settings.....	35
2.8.1.	Range Code .....	35
2.8.2.	Offset Settings.....	36
2.9.	Digital Output Power-on and Safe Values .....	37
2.9.1.	Digital Output Power-on Value.....	37
2.9.2.	Digital Output Safe Value.....	39

2.10.	Analog Output Power-on and Safe Values.....	40
2.10.1.	Analog Output Power-on value.....	40
2.10.2.	Analog Output Safe Value .....	42
2.11.	87K Digital Input Counter.....	43
2.12.	COM Port Settings.....	45
2.12.1.	COM Port Enable Modes .....	46
2.13.	Watchdog Timer (WDT) Settings .....	48
2.14.	Monitoring .....	50
2.15.	Trend Chart .....	53
2.16.	Data Log .....	56
2.17.	Save and Load the Configuration Settings.....	58
2.18.	Modbus RTU Master Tool .....	59
2.19.	Modbus TCP Client Tool.....	62
<b>3.</b>	<b>Linking to SCADA Software via Modbus .....</b>	<b>65</b>
3.1.	SCADA Expert Vijeo Citect.....	66
3.1.1.	Creating a New Project, an I/O Server and an I/O Device .....	66
3.1.2.	Designing the Layout and Acquiring the Data .....	74
3.2.	DASYLab .....	94
3.2.1.	Adding an Analog Input Channel .....	94
3.2.2.	Adding an Analog Output Channel .....	99
3.2.3.	Adding a Digital Input Channel .....	104
3.2.4.	Adding a Digital Output Channel .....	108
3.3.	EZ Data Logger .....	112
3.3.1.	Adding the I/O Modules to the Workgroup.....	112
3.3.2.	Designing the Layout and Acquiring Data.....	124
	<b>Appendix A: Backing Up and Restoring the EEPROM Settings .....</b>	<b>128</b>
1.	Backing up the Settings.....	129



2.	Restoring the Settings .....	132
<b>Appendix B: Function Codes (FC) .....</b>		<b>135</b>
1.	Read DO (0xxxx) .....	136
2.	Read DI (1xxxx).....	137
3.	Read AO (4xxxx) .....	138
4.	Read AI (3xxxx).....	139
5.	Write Single DO (0xxxx).....	140
6.	Write Single AO (4xxxx).....	141
7.	Write DO (0xxxx) .....	142
8.	Write AO (4xxxx) .....	143
<b>Appendix C: Range Codes for Analog Modules .....</b>		<b>144</b>
1.	87K Analog Modules .....	146
1.1.	Current and Voltage Type Definitions .....	146
1.2.	Thermocouple Type Definitions.....	151
1.3.	RTD (Resistance Temperature Detector) Type Definitions .....	153
1.4.	Thermistor Type Definitions .....	157
2.	8K Modules .....	160

# 1. Introduction

## 1.1. Introduction to the User Manual

Modbus is a very common protocol used in the industrial manufacturing and environment monitoring fields. The Modbus Utility provided by ICP DAS can be used to communicate with a Host controller to retrieve data from remote modules.

This manual describes how to use the Modbus Utility in conjunction with controllers that support the Modbus protocol. Also included are instructions for linking SCADA (Supervisor Control and Data Acquisition) software to Modbus devices.

This manual applies to following controllers and modules.

Model	I/O Slots	CPU	SRAM	Flash	Memory Expansion	Ethernet	RS-232 /485
I-8430	4	40 MHz	512 KB	512 KB	-	1 (10BASE-T)	3
I-8830	8						
I-8431-MTCP	4						
I-8331-MTCP	8						
I-8431-80-MTCP	4	80 MHz	768 KB	-	Micro SD	2 (10/100 BASE-Tx)	4
I-8831-80-MTCP	8						
I-8KE4-MTCP-G	4						
I-8KE8-MTCP-G	8						
IP-8441-MTCP	4	-	-	-	-	-	1
IP-8841-MTCP	8						
ET-87P4-MTCP	4	40 MHz	512 KB	512 KB	-	1 (10BASE-T)	2
I-7188EX(D)-MTCP	-		384 KB				
I-7188E2(D)-MTCP	-		512 KB				
μPAC-7186EX(D)-MTCP	-	80 MHz	512 KB	-	-	1 (10/100 BASE-Tx)	-

## 1.2. Modbus Protocol

### 1.2.1. What is the Modbus protocol?

Modbus is a communication protocol originally developed for Modicon controllers by Modicon Inc. in 1979. Modbus is a standard, truly open protocol and is the most widely used network communication protocol in the industrial automation field. SCADA (Supervisor Control and Data Acquisition) and HMI (Human-Machine Interface) software can be used to easily integrate serial devices via the Modbus protocol.

### 1.2.2. What is the Modbus/TCP protocol?

The Modbus/TCP protocol is a variant of the original Modbus protocol that was developed in 1999 to allow access to Ethernet devices by the Internet community.

### 1.2.3. What software supports the Modbus and Modbus/TCP protocol?

Most SCADA and HMI software packages include support for the Modbus protocol. For example: ControlMaestro, DASyLab([Section 3.2](#)), EZ Data Logger([Section 3.3](#)), Iconics GENESIS32/64, iFIX, InduSoft Web Studio, LabView, Trace Mode, StruxureWare SCADA Expert Vijeo Citect([Section 3.1](#)), Wonderware Intouch, etc.

### 1.2.4. What are the benefits of using Modbus and Modbus/TCP?

- A. Open source, no license fees
- B. Widely supported by SCADA and HMI software
- C. Easy to use
- D. Easily integrated with a variety of devices
- E. Low development cost
- F. Wide knowledge base

### 1.2.5. Modbus Resources

- A. <http://www.modbus.org>

A community for Modbus users.

- B. [http://www.modbustools.com/modbus\\_activex.asp](http://www.modbustools.com/modbus_activex.asp)

An ActiveX control that can be used to communicate with a Modbus slave device via the Modbus (RTU/ASCII) or Modbus/TCP protocols.

### 1.3. Default Firmware Features

When purchased, the IP-8000-MTCP/I-8000-MTCP controller already contains the default Modbus firmware installed Flash memory, and includes the following features.

#### 1.3.1. Support for the Modbus/TCP communication protocol that allows access to I/O devices inserted in the I/O slots

The default firmware allows the controller to be connected via Ethernet in order to transmit Modbus commands in Modbus/TCP protocol format.


#### 1.3.2. Support for the VxComm technique for all COM ports on connected controllers

Even if a serial device doesn't support the Modbus/RTU protocol, it can still be accessed via Ethernet. However, the VxComm driver will first need to be installed on the Host PC and the COM ports assigned in order to link to the COM ports on the controller. Once installed, the serial clients will then be able to access these remote serial devices via Ethernet using standard RS-232 functions.

The latest VxComm driver for Windows XP (or later) can be downloaded from: [http://ftp.icpdas.com/pub/cd/8000cd/napdos/driver/vxcomm\\_driver/2k/](http://ftp.icpdas.com/pub/cd/8000cd/napdos/driver/vxcomm_driver/2k/)

#### 1.3.3. Automatic I/O module scanning

Once a connection is created, the default firmware will automatically scan all the I/O slots of any connected modules and then display the module information in the "Summary" table which will be describe in more detail in Section 2.1, as illustrated below.



DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Slot	Module	DI (1xxx) address	Points	DO (0xxx) addre...	Points	AI (3xxx) address	Points	AO (4xxx) addre...	Points
1	I-87005	-	-	-	-	-	-	-	-
2	I-87028...	-	-	-	-	-	-	00 [00]	8
3	I-87055	00 [00]	8	00 [00]	8	-	-	-	-
ALL	Status	08 [08]	4	-	-	-	-	-	-

#### **1.3.4. Automatic assignment of a register address for the I/O modules**

An I/O module can be inserted into any slot, and the Modbus firmware will automatically scan all slots and assign the I/O channels to the registers in a continuous range. The register mapping for all the I/O channels can be retrieved by connecting to the controller using the Modbus Utility.

#### **1.3.5. Allows simultaneous access by multiple clients (or masters)**

Different controllers support a different number of connections to a client. For more details, refer to the FAQ on the ICPDAS web site.

<http://www.icpdas.com/faq/7188e/hardware/003.htm>

#### **1.3.6. Online configuration via Ethernet using the Modbus Utility**

#### **1.3.7. Supports I-8000 and I-87000 series I/O modules**

#### **1.3.8. Updateable and programmable firmware**


The Modbus SDK provided by ICP DAS allows users to develop custom Modbus firmware. For more details related to the IP-8000-MTCP, refer to the following:

<http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/ip8000/demo/bc/>

## 1.4. Typical Applications


### 1.4.1. Basic Application 1: Modbus TCP I/O Device

An I-8000-MTCP running the default firmware operates as a Modbus/TCP slave I/O device. Use the Modbus Utility to configure the device and then create a connection between the SCADA/HMI software and the I-8000-MTCP.




### 1.4.2. Basic Application 2: Modbus/RTU to Modbus/TCP Converter

After setting the COM Port to Gateway mode via the Modbus Utility, the Modbus/RTU device can be linked to the I-8000-MTCP using the Modbus/TCP protocol. The SCADA/HMI software can then be configured to convert the Modbus/RTU device to a Modbus/TCP device.



### 1.4.3. Basic Application 3: Modbus/TCP I/O Device using the VxComm Technique

An I-8000-MTCP is also able to link serial devices that are connected to the COM ports on the I-8000-MTCP device. To use this function, the VxComm driver first needs to be installed on the Host PC. After the driver is installed, the remote COM ports can be accessed via the standard serial driver.






#### 1.4.4. Advanced Application 1: User-defined Modbus/TCP Controller

Using the Modbus SDK, custom firmware can be developed that allows access to additional functions, together with the integration of serial devices with the Modbus/TCP kernel, making the I-8000-MTCP a powerful controller. For demo of user-defined SDK related to the I-8000-MTCP, refer to the following:

<http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/8000e/demo/bc/>

#### 1.4.5. Advanced Application 2: Modbus/TCP Controller using the VxComm Technique

If an I-8000-MTCP controller is used to link the same hardware devices as described in Advanced Application 1 above, and if any of devices connected to specific COM ports are not integrated into the custom firmware, the COM ports can still be accessed using the standard serial driver. However, in order to do this, the VxComm driver must first be installed on the Host PC.




#### 1.5. Supported Modules

For details of which I/O modules are supported by the different controllers, go to [http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/8000e/document/mbt8\\_support\\_modules.htm](http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/8000e/document/mbt8_support_modules.htm)

# 2. Starting the Modbus Utility


The following is an overview of the process flow used to establish a connection between the controller and the Modbus Utility, then retrieve the I/O data and set the I/O values.



The latest version of the Modbus Utility installation file can be downloaded from: [http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/modbus\\_utility/](http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/modbus_utility/)

## 2.1.Introduction to the User Interface


The following is an illustration of the main user interface of the Modbus Utility.




- A. Menu Bar
- B. Toolbar
- C. Connection Panel
- D. Power-on Value, Safe Value ,Offset and DI Counter Settings Panel
- E. Controller Panel and Module Panel
  - Left-hand side: COM Ports and Watchdog Timer (WDT) Settings
  - Right-hand side: Module Setting Panel.
- F. Address Table (Mapping Table)

**Note:** If the warning message shown below is displayed after executing the Modbus Utility, restart the program by right-clicking the shortcut and choosing "Run as administrator" to open the application with Administrator privileges.

Alternatively, right click the application shortcut, and choose "Properties". Click the "Compatibility" tab and then click the "Run this program as an administrator" checkbox. This method will configure the Utility to always run with Administrator privileges.



**Right-click the Modbus Utility shortcut**



## 2.2. Updating the Firmware

The “Update Firmware” function is used to update the firmware to the latest version. The firmware can be updated using either a COM port or a UDP connection. However, ensure that the LAN1 on the controller is connected to the network or COM1 port on the controller is connected to the computer before attempting to update the firmware, otherwise the update process will fail.

### 2.2.1. Updating via Ethernet


**Step 1:** Reboot the controller in INIT mode.

For I-8000 modules, short the INIT\* and INIT\*COM pins.


For IP-8000 and ET-87PN modules, move the DIP switch to the “Init” position.

For 7188E devices, short the INIT\* and GND pins.


**Step 2:** Execute the Modbus Utility and select the Modbus/TCP controller mode.




**Step 3:** Select the “Update Firmware” option from the “Client Tools” menu to connect to the controller.



In the Update Firmware window, select the UDP option from the drop-down menu. If IP address is known, enter the details in the text field and then click the “Connect” button. Alternatively, click the “Search IP” button to search for available controllers on the LAN, and then double-click IP address in the search result to establish a connection to the controller.




After a connection is established, the firmware file for the controller will be listed in the “Update Firmware” tab, as shown in the diagram below.






**Step 4:** Before the firmware can be updated, all existing files must be deleted. Click the “Erase Disk” button to delete all the files currently existing on the controller.



**Step 5:** Select the new firmware file and then click the “Upload >>” button to upload the new firmware to the controller. A progress indicator will be displayed to show the status of the update. After the update process is completed, the new file will be displayed in the file list. If it is not displayed, click the “Refresh file list” button to display the latest files.

The firmware has now been successfully updated. The device must be rebooted before the new firmware becomes effective. If the update fails, go to step4 to update again.



## 2.2.2. Updating via a Serial Port


**Step 1:** Reboot the controller in INIT mode.

For I-8000 modules, short the INIT\* and INIT\*COM pins.


For IP-8000 and ET-87PN modules, move the DIP switch to the “Init” position.

For 7188E devices, short the INIT\* and GND pins.

**Step 2:** Execute the Modbus Utility and select the Modbus/TCP controller mode.




**Step 3:** Select the “Update Firmware” option from the “Client Tools” menu to connect to the controller.






In the Update Firmware window, select the required COM port from the drop-down menu and then click the "Connect" button. After a connection is established, the firmware file for the controller will be listed in the "Update Firmware" tab, as shown in the diagram below.

**Note:** The default COM port settings are "115200, N, 8, 1".




**Step 4:** Before the firmware can be updated, all existing files must be deleted. Click the "Erase Disk" button to delete all the files currently existing on the controller.



**Step 5:** Select the new firmware file and then click “Upload >>” button to upload the new firmware to the controller. A progress indicator will be displayed to show the status of the update. Once the update process is completed, the new file will be displayed in the file list. If it is not displayed, click the “Refresh file list” button to display the latest files.

The firmware has now been successfully updated. The device must be rebooted before the new firmware becomes effective. If the update fails, go to step4 to update again




## 2.3. Network Settings

Before beginning the configuration process, ensure that either LAN1 or LAN2 ports on the controller are connected to your network. Two methods can be used to configure the network using a UDP connection.


### 2.3.1. Method 1: Under Running Firmware Mode

**Step 1:** Make the controller under the running firmware mode.


**Step 2:** Execute the Modbus Utility and select the Modbus/TCP controller mode.




**Step 3:** Select the "UDP Search" option from the "Client Tools" menu to open the eSearch Utility.




**Step 4:** In the eSearch Utility window, click the “Search Servers” button to search for any controller connected to the LAN.



**Step 5:** Once the search is complete, select the controller that is to be configured and then click the “Configuration (UDP)” button.



Enter the required details in the DHCP, IP Address, Sub-net Mask, Gateway, and Alias fields, and then click the “OK” button to save the settings.



### 2.3.2. Method 2: While Operating in INIT Mode


**Step 1:** Reboot the controller in INIT mode.

For I-8000 modules, short the INIT\* and INIT\*COM pins.


For IP-8000 and ET-87PN modules, move the DIP switch to the “Init” position.

For 7188E devices, short the INIT\* and GND pins.

**Step 2:** Execute the Modbus Utility and select the Modbus/TCP controller mode.




**Step 3:** Select the “Update Firmware” option from the “Client tools” menu.






**Step 4:** In the Update Firmware window, select the UDP option from the drop-down menu, and click the "Search IP" button to search for available controllers connected to the LAN. Once the search is complete, select an IP address and then click the "Connect" button to establish a connection.



**Step 5:** In the Update Firmware window, select the "Network Settings" tab and then click the "Get Settings" button. The current network settings will be displayed in the text fields for LAN1. Edit the settings as required and then click the "Save Settings" button to save the new settings.




After the new network are saved, the Modus Utility will automatically connect to the controller using the new IP address.

## 2.4. Net ID (Station Number) Settings

The Net ID is a hexadecimal value that can range from 01 to FF and must be unique in the network. Set the Net ID by following the procedure described below.

**Step 1:** The Net ID is set using the 8-bit DIP switch located on the right-hand side of the controller. To set the Net ID, move the DIP switch for the required bit to the ON position. The following figure shows the Net ID for the controller. Bits 1 and 2 are in the ON position and the others are set to OFF, meaning that the Net ID for the controller is 3.



**Step 2:** Reboot the controller to enable the new Net ID

**Step 3:** After reconnecting to the controller, the Net ID for the controller will be displayed in the connection panel as described in [Introduction to the User Interface](#) (Item C).

```
I-8831 NetID=3
```




## 2.5. Connecting to the Controller


Before performing the following operation, ensure that the controller is set to "Run Firmware" mode, insert the modules, and then turn on the power.

### 2.5.1. Connecting via the Ethernet (Modbus/TCP)

**Step 1:** Execute the Modbus Utility and select the Modbus/TCP controller mode.




**Step 2:** Enter the IP address for the controller in the Connection Panel described in [Introduction to the User Interface](#) (Item C), and then click the "Connect" button. If a connection is successfully established, the connection status will be displayed in the text field indicated in the image below.




## 2.5.2. Connecting via a Serial Port (Modbus/RTU)


**Step 1:** Execute the Modbus Utility and select the Modbus/RTU controller mode.




**Step 2:** In the Connection Panel described in [Introduction to the User Interface](#) (Item C), select the COM port and click “Connect” on the connect panel. It will open a Search List window in the next step to search for required device on the selected COM port.




**Step 3:** Click the “Search” button to search for any available devices. Once the required device has been located, click the “Stop” button to stop searching.



**Step 4:** Select the Net ID from the search result list, and then click the “Connect to Selected ID” button to establish a connection.




If COM port is successfully opened, the status will be displayed in the text field indicated in the image below.



### 2.5.3. Refreshing the Configuration after Connecting

If the current configuration for any of the modules on the controller does not match the setting stored in the EEPROM, click the “Refresh” button to save the current configuration to the EEPROM.



## 2.6. Address Table (Mapping Table)

After connecting to the module, click the **Summary** tab in the address/mapping table dialog to check the information related to the module, including the slot number for the module and addresses of the I/O channels (points).

**Note:** The I/O addresses listed here are Base 0.

DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Slot	Module	DI (1xxx) address	Points	DO (0xxx) address	Points	AI (3xxx) address	Points	AO (4xxx) address	Points
1	I-87040	00 [00]	32	-	-	-	-	-	-
2	I-8014-SE	-	-	-	-	00 [00]	16	-	-
ALL	Status	32 [20]	4	-	-	-	-	-	-

Address starts from 0

## 2.7. Library Version

The library version depends on the version of the installed firmware. The latest version of the firmware can be obtained from the following locations.

For 7188E:

<http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/7188e/firmware/>

For ET-87PN:

<http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/et87pn/firmware/>

For I-8000-MTCP:


<http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/8000e/firmware/>

For IP-8000-MTCP:


<http://ftp.icpdas.com/pub/cd/8000cd/napdos/modbus/ip8000/firmware/>

Use the procedure described below to check the version information for the current library:


**Step 1:** Select the “About” option from the “Help” menu.



**Step 2:** The version information will be displayed in the Modbus Utility “About” dialog box.



The Modbus Library and the I/O scan Library are related to the firmware name. The version information is shown in the firmware name.



## 2.8. Analog Module Range Code and Offset Settings

To change the Range Code and Offset settings of Analog modules, click the module that is to be configured to display the Range Code Settings Panel.




The example shown here is for the I-87028U module.

### 2.8.1. Range Code

The Range code is used to set the maximum and minimum input/output range for the Analog modules and only valid signals within this range will be transmitted.


Configure the Range Code settings in the Settings Panel by selecting the appropriate Input/Output Range from the drop-down menu(s) for the respective channel(s), and then click the “Set All” button to apply the new settings.



The Range Code types and definitions for Analog modules are shown in [Appendix C: Range Codes for Analog Modules](#).

### 2.8.2. Offset Settings

An offset value can be set to compensate for any inaccuracies that exist in the module. To configure the Offset value in the Range Code Settings Panel, enter the required value in the Offset text field(s) for the respective channel(s), and then click the “Set All” button to apply the new settings.





## 2.9. Digital Output Power-on and Safe Values

To change the Digital Output Power-on and Safe values, click the module that is to be configured to open the DIO Settings Panel.



The example shown here is for the I-87061 module.

### 2.9.1. Digital Output Power-on Value

The Power-on value is the Digital Output value that will be set for the module every time the controller is powered on.

**Step 1:** In the DIO Settings Panel, click the “DO Power-on” tab, check the checkbox(es) for the channel(s) to be set, and then click the “Set DO Power-on Value” button to apply the new Power-on value(s).



**Step 2:** The controller must be rebooted before the new Power-on value settings become effective. After rebooting, the Power-on value(s) for the channel(s) will be displayed in the table on the DO Mapping tab in monitoring mode, or check the output LEDs.

DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Digital Output [0xxxx]									
Address	Module	Slot	Channel	Value	Comment				
00 [00]	I-87061	2	0	0	[40]Digital module				
01 [01]	I-87061	2	1	0	[40]Digital module				
02 [02]	I-87061	2	2	0	[40]Digital module				
03 [03]	I-87061	2	3	0	[40]Digital module				
04 [04]	I-87061	2	4	0	[40]Digital module				
05 [05]	I-87061	2	5	0	[40]Digital module				
06 [06]	I-87061	2	6	0	[40]Digital module				
07 [07]	I-87061	2	7	0	[40]Digital module				
08 [08]	I-87061	2	8	0	[40]Digital module				


DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Digital Output [0xxxx]									
Address	Module	Slot	Channel	Value	Comment				
00 [00]	I-87061	2	0	1	[40]Digital module				
01 [01]	I-87061	2	1	1	[40]Digital module				
02 [02]	I-87061	2	2	1	[40]Digital module				
03 [03]	I-87061	2	3	0	[40]Digital module				
04 [04]	I-87061	2	4	0	[40]Digital module				
05 [05]	I-87061	2	5	0	[40]Digital module				
06 [06]	I-87061	2	6	0	[40]Digital module				
07 [07]	I-87061	2	7	0	[40]Digital module				
08 [08]	I-87061	2	8	0	[40]Digital module				

**After rebooting the controller, the Power-on values for channel 0 to 2 which are used in this example will be displayed.**

## 2.9.2. Digital Output Safe Value

If Modbus communication with the controller is lost for longer than the defined timeout period, the Host Watchdog will be triggered and all modules will be set to a preset Safe Value.

In the DIO Settings Panel, click the “DO Safe Value” tab, check the checkbox(es) for the channel(s) to be set, and then click the “Set DO Safe Value” button to apply the Safe value(s).



Once the Host Watchdog has been reset the modules, the DO value will be set to the Safe value.

Address	Module	Slot	Channel	Value	Comment
08 [08]	I-87061	2	8	0	[40]Digital module
09 [09]	I-87061	2	9	0	[40]Digital module
10 [0A]	I-87061	2	10	0	[40]Digital module
11 [0B]	I-87061	2	11	0	[40]Digital module
12 [0C]	I-87061	2	12	0	[40]Digital module
13 [0D]	I-87061	2	13	0	[40]Digital module
14 [0E]	I-87061	2	14	0	[40]Digital module
15 [0F]	I-87061	2	15	0	[40]Digital module

**Once the Host Watchdog has been reset, the Safe values will be displayed for channel 13 to 15 which are used in this example.**

Address	Module	Slot	Channel	Value	Comment
12 [0C]	I-87061	2	12	0	[40]Digital module
13 [0D]	I-87061	2	13	1	[40]Digital module
14 [0E]	I-87061	2	14	1	[40]Digital module
15 [0F]	I-87061	2	15	1	[40]Digital module

## 2.10. Analog Output Power-on and Safe Values

To change the Analog Output Power-on and Safe values, click the module that is to be configured to open the Range Code Settings Panel.



The example shown here is for I-87028C module.

### 2.10.1. Analog Output Power-on value

The Power-on value is the Analog Output value that will be set for the module every time the controller is powered on.

**Step 1:** In the Range Code Settings Panel, configure the Power-on value(s) by entering the required Power-on value in the Power-on field(s) for the respective channel(s), and then click the “Set All” button to apply the new settings.

	Input/Output Range	Offset (Dec)	Power-on (Value)	Safe (Value)
Ch0	+0.0 To +20.0 mA	0	2	0.000
Ch1	+0.0 To +20.0 mA	0	0.000	0.000
Ch2	+0.0 To +20.0 mA	0	0.000	0.000
Ch3	+0.0 To +20.0 mA	0	0.000	0.000
Ch4	+0.0 To +20.0 mA	0	0.000	0.000
Ch5	+0.0 To +20.0 mA	0	0.000	0.000
Ch6	+0.0 To +20.0 mA	0	0.000	0.000
Ch7	+0.0 To +20.0 mA	0	0.000	0.000

**Step 2:** The controller must be rebooted before the new Power-on value settings become effective. After rebooting, the Power-on value for the channel will be displayed in the AO Mapping tab in monitoring mode, or a monitoring tool can be used to detect the value.

The image displays two screenshots of the 'AO Mapping' tab in monitoring mode, illustrating the change in the Power-on value for channel 0 after a controller reboot.

**Top Screenshot (Before Reboot):**

Address	Module	Slot	Channel	Value	Comment
00 [00]	I-87028C	1	0	0.000	[0] +0.0 To +20.0 mA
01 [01]	I-87028C	1	1	0.000	[30] +0.0 To +20.0 mA
02 [02]	I-87028C	1	2	0.000	[30] +0.0 To +20.0 mA
03 [03]	I-87028C	1	3	0.000	[30] +0.0 To +20.0 mA
04 [04]	I-87028C	1	4	0.000	[30] +0.0 To +20.0 mA
05 [05]	I-87028C	1	5	0.000	[30] +0.0 To +20.0 mA
06 [06]	I-87028C	1	6	0.000	[30] +0.0 To +20.0 mA
07 [07]	I-87028C	1	7	0.000	[30] +0.0 To +20.0 mA

**Bottom Screenshot (After Reboot):**

Address	Module	Slot	Channel	Value	Comment
00 [00]	I-87028C	1	0	2.000	[0] +0.0 To +20.0 mA
01 [01]	I-87028C	1	1	0.000	[30] +0.0 To +20.0 mA
02 [02]	I-87028C				
03 [03]	I-87028C				
04 [04]	I-87028C				
05 [05]	I-87028C				
06 [06]	I-87028C				
07 [07]	I-87028C				

**Callout Text:** After rebooting the controller, the Power-on value for channel 0 which is used in this example will be displayed.

## 2.10.2. Analog Output Safe Value

If Modbus communication with the controller is lost for longer than the defined timeout period, the Host Watchdog will be triggered and all modules will be set to a preset Safe Value.

In the Range Code Settings Panel, configure the Safe value(s) by entering the required value in the Safe Value field(s) for the respective channel(s), and then click the “Set All” button to apply the new settings.

**Range Code**

Ch0~Ch7

Channel	Input/Output Range	Offset (Dec)	Power-on (Value)	Safe (Value)
Ch0	+0.0 To +20.0 mA	0	0.000	0.000
Ch1	+0.0 To +20.0 mA	0	0.000	0.000
Ch2	+0.0 To +20.0 mA	0	0.000	0.000
Ch3	+0.0 To +20.0 mA	0	0.000	0.000
Ch4	+0.0 To +20.0 mA	0	0.000	0.000
Ch5	+0.0 To +20.0 mA	0	0.000	0.000
Ch6	+0.0 To +20.0 mA	0	0.000	0.000
Ch7	+0.0 To +20.0 mA	0	0.000	5

Set All

Once the Host Watchdog has been reset, the DO value will be set to the Safe value.

Address	Module	Slot	Channel	Value	Comment
00 [00]	I-87028C	1	0	0.000	[30] +0.0 To +20.0 mA
01 [01]	I-87028C	1	1	0.000	[30] +0.0 To +20.0 mA
02 [02]	I-87028C	1	2	0.000	[30] +0.0 To +20.0 mA
03 [03]	I-87028C	1	3	0.000	[30] +0.0 To +20.0 mA
04 [04]	I-87028C	1	4	0.000	[30] +0.0 To +20.0 mA
05 [05]	I-87028C	1	5	0.000	[30] +0.0 To +20.0 mA
06 [06]	I-87028C	1	6	0.000	[30] +0.0 To +20.0 mA
07 [07]	I-87028C	1	7	0.000	[30] +0.0 To +20.0 mA


**Once the Host Watchdog has been reset, the Safe value will be displayed for channel 7 which is used in this example.**

Address	Module	Slot	Channel	Value	Comment
05 [05]	I-87028C	1	5	0.000	[30] +0.0 To +20.0 mA
06 [06]	I-87028C	1	6	0.000	[30] +0.0 To +20.0 mA
07 [07]	I-87028C	1	7	5.000	[30] +0.0 To +20.0 mA



## 2.11. 87K Digital Input Counter

Each Digital Input channel on an 87K series module can also be used as a Low-speed (<100 Hz) counter. Click the module that is to be configured to open the DIO Settings Panel.



The example shown here is for the I-87046 module.

**Step 1:** In the DIO Settings Panel, click the “DI Counter” tab, check the checkbox(es) for the channel(s) to be set, and then click the “Set DI Counter” button to apply the new Counter Settings.



Any channel that have been set as a DI counter will be displayed in the “AI Mapping” tab.

Address	Module	Slot	Channel	Value	Comment
00 [00]	I-87046	3	0		[40] Low Speed Counter
01 [01]	I-87046	3	1		[40] Low Speed Counter
02 [02]	I-87046	3	2		[40] Low Speed Counter



**Step 2:** After the counter(s) for the DI channel(s) have been set, click the “AI Mapping” tab to display the channels that have associated counters, together with the current values for the counter.

**Note:** Before the current counter values can be read, the [Monitoring](#) function needs to be enabled.

DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Analog Input (3xxxx)									
Address	Module	Slot	Channel	Value	Comment				
00 [00]	I-87046	3	0	27	[40] Low Speed Counter				
01 [01]	I-87046	3	1	24	[40] Low Speed Counter				
02 [02]	I-87046	3	2	17	[40] Low Speed Counter				

**Step 3:** To clear counter value, click the “DO Mapping” tab and then **double-click** the value for the relevant channel. The counter value for that channel will then be set to 0. Channel 0 is used as an example here.

DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Analog Input (3xxxx)									
Address	Module	Slot	Channel	Value	Comment				
00 [00]	I-87046	3	0	27	[40] Low Speed Counter				
01 [01]	I-87046	3	1	24	[40] Low Speed Counter				
02 [02]	I-87046	3	2	17	[40] Low Speed Counter				

DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Digital Output (0xxxx)									
Address	Module	Slot	Channel	Value	Comment				
00 [00]	I-87046	3	0	0	Clear Counter				
01 [01]	I-87046	3	1	0	Clear Counter				
02 [02]	I-87046	3	2	0	Clear Counter				


**Double-click the Value field for channel 0.**

DI Mapping		DO Mapping		AI Mapping		AO Mapping		Summary	
Analog Input (3xxxx)									
Address	Module	Slot	Channel	Value	Comment				
00 [00]	I-87046	3	0	0	[40] Low Speed Counter				
01 [01]	I-87046	3	1	24	[40] Low Speed Counter				
02 [02]	I-87046	3	2	17	[40] Low Speed Counter				


**The counter value for channel 0 will be reset to zero.**

## 2.12. COM Port Settings


To adjust the configuration for the COM ports, click the COM port icon in the Controller Panel described in [Introduction to the User Interface](#) (Item E) to display the “COM Port Settings” panel.



**Step 1:** Select the COM port to be configured from the drop-down menu, and then select the Enable mode, and the Modbus timeout, and select the appropriate values for the other settings. Seven modes can be selected for the COM port. Once all the relevant values have been selected, click the “Set” button to apply the new settings.




The new settings will be displayed in the “System Settings” panel immediately.



### 2.12.1. COM Port Enable Modes

Seven modes can be selected for the COM port, each of which are described below.

- A. VxComm: This option creates virtual COM ports and maps them to the Ethernet ports on the serial modules.
- B. Modbus RTU Gateway: This option allows the COM port to connect to up to 255 RTU slaves (stations). Enter the number of devices connected to the Modbus RTU gateway in the “Stations per COM Port” text field and then click the “Set” button. The Modbus Utility will automatically assign the Slave ID if more than one port is set to the Modbus RTU gateway mode.



C. Modbus RTU Slave: This option is used to set the device to operate as a Modbus RTU Slave.

D. Modbus ASCII Slave: This option is used to set the device to operate as a Modbus ASCII Slave.

E. Programming: This option is used for programming purpose only and will not automatically detect Modbus requests.


F. Debug: This option is used to display debug messages relating to Modbus requests, or communication messages, etc. while communicating with a Modbus master or Modbus clients.

G. Console: This option is used to perform configuration for file uploads, or updating the firmware for the device.

## 2.13. Watchdog Timer (WDT) Settings

Each ICP DAS controller contains a Host Watchdog that will be activated if the controller either crashes or otherwise malfunctions for some reason. The Watchdog Timer can be set to a specified period and is used to count the time since Modbus communication with the controller was lost. When the Watchdog Timer counter reaches zero, the Host Watchdog will be activated and all Analog/Digital Output modules will be set to their predetermined Safe values and the L3 LEDs on the panel will flash to indicate that an error has occurred.

Click the Watchdog icon in the Controller Panel described in [Introduction to the User Interface](#) (Item E) to open the WDT Settings panel.




**A. CPU Reset Status:** This parameter is used to indicate whether the current system status was set during a normal power-on event or whether it was reset by the CPU Watchdog.

**During Power on:** This status message will be displayed if the controller was started normally.

**By CPU WDT:** This status message will be displayed if the controller encountered an error that caused the CPU Watchdog to reboot the controller.

B. CPU Reset Event: This parameter is used to indicate the number of times the controller has been reset due to CPU and power-on events. Clicking the “Clear” button will reset the counter to 0.

C. Watchdog Timer Duration: This parameter is used to set the duration of the Watchdog Timer and must be set between 0 and 65535 seconds. To enable the Watchdog Timer, enter the required duration (must be set to more than 5 seconds) and then click the “Set” button to apply the new duration.




D. WDT Event Count: This parameter is used to indicate the number of times the controller has been reset due to Watchdog Timer events. Clicking the “Clear” button will reset the counter to 0.




## 2.14. Monitoring

The Monitor function is used to timely retrieve the current I/O values and to also set the output values for modules.

**Step 1:** To set the timer scan interval, click the arrow on right-hand side of the "Monitor" button in the toolbar and then click "Timer Interval".



**Step 2:** Click the "Monitor" button in the tool bar to begin scanning. After the monitoring process begins, the "Monitor" button will be displayed as active, as illustrated below. To stop the monitoring process, click the "Monitor" button again.




The I/O values displayed in the Mapping table will be automatically refreshed periodically, but the frequency of the updates depends on the value set for the timer interval. Here use the DI Mapping Table as an example.


Address	Module	Slot	Channel	Value	Comment
00 [00]	I-87046	3	0	0	[0] Digital Module
01 [01]	I-87046	3	1	1	[4] Digital Module
02 [02]	I-87046	3	2	0	[4] Digital Module
03 [03]	I-87046	3	3	0	[4] Digital Module
04 [04]	I-87046	3	4	0	[4] Digital Module
05 [05]	I-87046	3	5	0	[4] Digital Module
06 [06]	I-87046	3	6	0	[4] Digital Module
07 [07]	I-87046	3	7	0	[4] Digital Module
08 [08]	I-87046	3	8	0	[4] Digital Module




**Step 3:** The display mode for analog modules can be changed to either Value, Decimal or Hexadecimal format. Click the arrow for the “Scale” button in the toolbar and select the desired option from the drop-down list.




**Step 4:** To change the output values for a specific channel on an Analog Output module, click the “AO Mapping” tab and then double-click the row to relevant channel to open the “Channel” dialog box for that channel. Enter the required value and then click the “OK” button. The value for the channel will be changed immediately.



**Step 5:** To change the output value for a specific channel on a Digital Output module, click the “DO Mapping” tab and then double-click the row for the relevant channel. The value to the channel will be changed immediately. The value, 0, represents the status OFF, and the value, 1, represents the status ON.




**Note:** The Modbus Utility also includes an alert system that warns when an 87K module is offline. If the module is offline, the image for the module will be displayed in red and the value in the DI Mapping table will be shown as 0. Both the image and the value will return to normal once the module is online.



## 2.15. Trend Chart


In addition to retrieving data values from the address table, the Trend function can be used to monitor data and display it as a trend chart. The following illustration is the interface for the Trend function.




- A. Settings and control area: This area is used to set the conditions for the monitoring functions, such as adding an address to be tracked, starting, pausing or stopping the monitoring, and adjusting the scope of the trend chart.
- B. Trend Chart List area: this area is used to display details of the addresses and other settings that have been selected to be tracked. The settings for the respective address can be adjusted, and the output values for the DO/AO addresses can be set.
- C. Track area: There are four areas that the Trend function uses to monitor and display the tracked data, indicated as Track 1, Track 2, Track 3 and Track 4 in the image above. Note that Track 1 can only be used to display trend lines for analog modules, while Track 2 to 4 are used to display the trend lines for digital modules.

The following procedures indicate that how to retrieve I/O data.

**Step 1:** Click the “Trend” button on the main menu to open the “Scope” dialog box.




**Step 2:** To record I/O data in the trend chart, select the I/O type and the address from the respective drop-down menus. Select a color for the chart line and assign a track number, and then click the “Add” button to add the record to the Track area.




After adding the address to the Track area, the address can be set to be visible or not in the Track area by clicking the checkbox or the line color can be changed by clicking the color column.

I/O	Address	Color	Track	Visible
AO	00 [00]	Green	1	<input checked="" type="checkbox"/>
DI	00 [00]	Brown	2	<input checked="" type="checkbox"/>
DI	02 [02]	Blue	3	<input type="checkbox"/>
DO	00 [00]	Light Green	2	<input checked="" type="checkbox"/>
DO	02 [02]	Cyan	3	<input checked="" type="checkbox"/>
DI	01 [01]	Yellow	3	<input checked="" type="checkbox"/>


**Step 3:** To set the output values for the DO addresses, click the address column to display the “Channel Information” dialog box. Click the “On” button to set the value of DO address to ON and click the “Off” button to set the value to OFF, and click the “Inverse” button to set the value to the inverse of the current value.



**Step 4:** To set the output values for the AO addresses, click the address column to display the “Channel Information” dialog box. Enter the output value and then click the “Set” button to apply the new settings.



**Step 5:** To change the scope range, click the “Axis” button to open the “Change Scope Range” dialog box. Adjust the settings as necessary and then click the “Set” button. The details shown in the “Change Scope Range” dialog box can also be fine-tuned by dragging either of the scale arrows illustrated in the image below.




## 2.16. Data Log

The data log function can be used to record the configuration of the modules, together with the current values, and then save the information as a text file.

**Note:** The Monitoring function must be active before the Data Log function can be activated.

**Step 1:** First, set a name for the log file by clicking the “Log File” option from the “Log” drop-down menu in the “Settings” menu to open an “Open” dialog box. If a name is not set for the log file, the default file name "yyyymmdd.txt" will be used and stored in the "log" subdirectory.



**Step 2:** Click the “Log” icon to begin recording log data. Once recording begins, the Log icon will change to indicate data logging is active, as shown below.





**Step 3:** To open the data log file, first click the “Log” icon to stop data recording, and then click the “Open Log” option in the “Log” drop-down menu to open the data log. The I/O data will be displayed in the data log text file.



20140409.txt - Notepad

```
File Edit Format View Help
Address reference mapping of Modbus TCP
iPAC8K NetID=1
I-87061(Slot0) + I-87028C(Slot1) + I-87028U(Slot2) + I-87046(Slot3) +
IP address: 192.168.2.193
Modbus firmware version: v1.7.2 [Jan 03 2012]
I/O scan lib version: v1.6.4 [Aug 12 2013]
Data: 4/9/2014
Time: 1:57:32 PM
```

Slot	Module	DI address	Point	DO address	Point	AI address	Point	AO address	Point
0	I-87061	-	-	00 [00]	16	-	-	00 [00]	8
1	I-87028C	-	-	-	-	-	-	08 [08]	8
2	I-87028U	-	-	-	-	-	-	-	-
3	I-87046	00 [00]	16	-	-	-	-	-	-
3	I-87046	-	-	16 [10]	3	00 [10]	3	-	-
ALL	Status	16 [10]	4	-	-	-	-	-	-

---

15 [0F] I-87028U 2 7 0 [30] +0.0 to +20.0 mA

Time, sampling,	[00]	[01]	[02]	[03]	[04]	[05]	[06]	[07]	[08]	[09]	[10]	[11]	[12]	[13]	[14]
13:57:32,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:33,	1,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:34,	2,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:35,	3,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:36,	4,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:37,	5,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:38,	6,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:39,	7,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:40,	8,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:41,	9,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:42,	10,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:43,	11,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:44,	12,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:45,	13,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:47,	14,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:48,	15,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:49,	16,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:50,	17,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:51,	18,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:52,	19,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:53,	20,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:54,	21,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:55,	22,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:56,	23,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:57,	24,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:58,	25,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:57:59,	26,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:00,	27,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:01,	28,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:02,	29,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:03,	30,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:04,	31,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:05,	32,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:06,	33,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:07,	34,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:08,	35,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,
13:58:09,	36,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,	0,


Ln1, Col1



## 2.17. Save and Load the Configuration Settings

The Modbus Utility allows the configuration of the module to be saved for future use, meaning that it can be loaded the next time the Modbus Utility is used without needing to set the configuration again.

After clicking the “Save” icon, the Modbus Utility will generate two files. The default file names are Modbus\_8E.ini and Modbus\_8E.txt.



Two methods can be used to review the settings of both a specific controller and each module that is inserted in it.

A. Using the Modbus Utility: Click the “Load” icon to load the .ini file into the Modbus Utility.




B. Using a text editor (such as Notepad): Open the .txt file in the text editor to view the details.



## 2.18. Modbus RTU Master Tool

The Modbus RTU (MBRTU) Master Tool can be used to send Modbus message to read or write I/O values via the COM port. The following image provides an overview of the MBRTU Master Tool interface.



A. COM Status: Click the "Open" button to connect to the controller using the selected COM Port and parameter values. Click the "Close" button to terminate the connection.

B. Protocol Description: This section provides a description of the request and the response. For more detailed information regarding this section, see [Appendix B: Function Codes \(FC\)](#)

C. Polling Mode: Set the timeout and then click the "Start" button to activate Polling Mode. Click the "Stop" button to cancel it.

Timer Mode: Used to set the timer interval (in million second) that must elapse

before a command is sent. Enter a value for the "Interval" and click the "Start" button to activate Timer Mode. Click the "Stop" button to cancel it.


D. Command: This section is used to enter commands. After entering a command, click the "Send Command" button to transmit the command.

E. Command/Response: Commands sent to the controller will be displayed in the left-hand text field, and the related response will be displayed on the right.

Use the following procedure to send a Modbus command.

**Step 1:** Set the COM Port mode to Modbus RTU Slave. For more details of the procedure, see [Section 2.12 COM Port Settings](#).

**Step 2:** Click the "Modbus/RTU Client" option from the "Clients tools" menu.



**Step 3:** In the COM Status section, select the COM Port and Baud Rate from the respective drop-down menus and then click the "Open" button to establish a connection to the COM Port.




**Step 4:** In the Command section, enter a command and then click the "Send Command" button to transmit the command. Ensure that the "Include CRC" option is checked to automatically add a Checksum to the end of the command.




**Step 5:** The command will be displayed on the left-hand side of the

Command/Response window, and the response will be shown on the right-hand side. Note that the last two bytes are the CRC.



## 2.19. Modbus TCP Client Tool

The Modbus TCP (MBTCP) Client Tool can be used to send Modbus messages to read or write I/O values via the Ethernet. The following image provides an overview of the MBTCP Client Tool interface.



- A. Modbus TCP: Click the “Connect” button to connect to the controller using the selected IP address and Port number. Click the “Disconnect” button to terminate the connection.
- B. Protocol Description: This section provides a description of the request and the response. Note that a 6-byte prefix must be used for the Modbus TCP protocol. For more detailed information regarding this section, see [Appendix B: Function Codes \(FC\)](#).
- C. Polling Mode: Click the “Start” button to activate Polling Mode and click the “Stop” button to cancel it.


Timer Mode: Used to set the timer interval (in million second) that must elapse before a command is sent. Enter a value for the "Interval" and then click the "Set" button. Click the "Start" button to activate Timer Mode and click the "Stop" button to cancel it

D. Command: This section is used to enter commands. Enter the command, including the 6-byte Modbus TCP prefix, and then click the "Send Command" button to transmit the command.


E. Command/Response: Commands sent to the controller will be displayed in the left-hand text field, and the related response will be displayed on the right.

Use the following procedure to send a Modbus command.

**Step 1:** Click the "Modbus/TCP Client" option from the "Clients Tools" menu.




**Step 2:** In the Modbus TCP section, enter the IP address and the Port number in the respective text fields and then click the "Connect" button to establish a connection. If you also wish to create a data log, click the "Data Log" checkbox.



**Step 3:** Enter a command in the command line field and then click the "Send Command" button to transmit the command.



**Step 4:** The command will be displayed on the left-hand side of the text box area, and the response will be shown on the right-hand side of the text box area.





## 3. Linking to SCADA Software via Modbus

This chapter provides a description of how to connect to SCADA (Supervisor Control and Data Acquisition) applications via Modbus in order to retrieve I/O values using the Modbus/TCP protocol. The SCADA applications that will be described in this chapter are:


- SCADA Expert Vijeo Citect
- DASyLab
- EZ Data Logger

### 3.1. SCADA Expert Vijeo Citect


In this section, a detailed description of the procedure for connecting the Vijeo Citect solution to a controller using the Modbus/TCP protocol is presented. In this example, Vijeo Citect version 7.40 is used.

#### 3.1.1. Creating a New Project, an I/O Server and an I/O Device


**Step 1:** Open the Vijeo Citect Explorer application from the Programs Menu.




**Step 2:** In the “Citect Explorer” window, click the “New” button to create a new project.




**Step 3:** In the “New Project” dialog box, enter a name for the new project. The name “Modbus Demo” is used in this example. Leave all other parameters at their default values, and then click the “OK” button to continue.




**Step 4:** In the Project List panel, expand the “Modbus Demo” folder, and then double-click the “Express I/O Device Setup” icon in the “Communications” folder to create a new I/O Server and I/O Device.




**Step 5:** Once the “Express Communications Wizard” screen is displayed, click the “Next >” button to continue.




**Step 6:** Click the “Create a new I/O Server” radio button, and enter “ModbusServer” in the Name field as the name of I/O Server, and then click the “Next >” button to continue.




**Step 7:** Click the “Create a new I/O Device” radio button, and enter “Dev\_8000” as the name of the I/O Device in the text field, and then click the “Next >” button to continue.



**Step 8:** Click the “External I/O Device” radio button to select the I/O Device type, and then click the “Next >” button to continue.




**Step 9:** Select the communication protocol by expanding the “Modicon” item, expanding “Quantum” item, and then clicking the “Modbus/TCP (Ethernet)” option. Click the “Next >” button to continue.






**Step 10:** Determine the IP address by checking the LED on the left-hand side of the controller, and then enter it in the “IP address” field. In this example, the IP address “192.168.2.199” is used. Enter the Port number in the “Port” field, “502” in this example, and then click the “Next >” button to continue.




**Step 11:** There is no need to select any options on the following screen, so click the “Next >” button to continue.







**Step 12:** Verify that the details for the new I/O Server are correct, and then click the "Finish" button to complete the configuration.



**Step 13:** In the "Communication" folder, double-click the "I/O Servers" icon to open the "I/O Server [Modbus Demo]" dialog box in the "Citect Project Editor" window.




**Step 14:** Find the Server named “ModbusServer” that was created in previous step. Enter the port number “502” in the “Port” text field and then click the “Replace” button to complete the I/O Server configuration.




### 3.1.2. Designing the Layout and Acquiring the Data


**Step 1:** Open the “Citect Project Editor” window, and then select the “I/O Devices” option from the Communication menu in order to modify the parameters for the I/O device that was created in [Section 3.1.1](#) above.




**Step 2:** Once the “I/O Devices [Modbus Demo]” dialog box is displayed, find the “Dev\_8000” device that was created in [Section 3.1.1](#). Determine the station number by checking the DIP switch on the right-hand side of the controller, and enter the value in the “Address” field. In this example, the station number “1” is used. To prevent the “Number” value entered in the “Address” field from being the same as the existing Server Number, enter “2” in the “Number” field. When all the relevant values have been entered, click the “Replace” button to complete the configuration.




**Step 3:** Open the “Citect Explorer” window, and expand the “Modbus Demo” folder in the Project List panel. Click the “Tags” folder and then double-click the “Variable Tags” icon in the Content pane to create a new variable tags.



**Step 4:** Open the “Citect Project Editor” window, enter a name for the tag in the “Tag Name” field in the “Variable Tags [Modbus Demo]” dialog box. Select the I/O device from the “I/O Device” drop-down menu, enter the correct address in the “Address” field, and select the appropriate “Data Type” from the drop-down menu. After the details for the first tag have been entered, click the “Add” button to save it.



Repeat the procedure to create the next tag.




The parameters for all tags used in this example are shown in the table below.

Tag Name	I/O Device Name	Data Type	Address	Eng. Scale
DO_0	Dev_8000	DIGITAL	00001	X
DI_0	Dev_8000	DIGITAL	10001	X
AO_0	Dev_8000	INT	40001	0~10
AI_0	Dev_8000	INT	30001	0~10

## Notes


- When using the Modbus protocol, the Address Type must be set to “0xxxx” for Digital Output, “1xxxx” for Digital Input, “3xxxx” for Analog Input, and “4xxxx” for Analog Output.
- The Digital Input and Digital Output are declared as Boolean data, and the Analog Input and Analog Output are declared as unsigned integer data.
- The “Starting Address” begins at “0001”. Thus, to use the 5th Digital Output channel, the “Address” field must be set to “10005”, and the Data Type must be set to “DIGITAL”. To use the 15th Analog Input channel, enter “30015” in the “Address” field, and set the Data Type to “INT”.

**Step 5:** Open the “Citect Graphics Builder” window, and click the “New...” option from the “File” menu to create a new page.






**Step 6:** In the "New" dialog box, click the "Page" button to create a new page using a pre-defined template.




**Step 7:** In the "Template" dialog box, click the "normal" option to select the template to be used for the page, and then click the "OK" button to continue.







**Step 8:** Click and hold the "New Button" icon and then drag and drop it onto the blank page to add a new button to the page.




**Step 9:** After releasing the mouse button, the "Button Properties" dialog box will be displayed. Click the "Appearance" tab and click the "Text" radio button and then enter "DO Button" in the "Text" field. This will be the label displayed on the button.




Click the "Input" tab and check the "Up" checkbox then enter "Toggle(DO\_0)" in the "UP command" text field. Click the "OK" button to save the changes.




**Step 10:** Click and hold the "LED Object" icon and then drag and drop it onto the page to add a new LED object to the page.




**Step 11:** After releasing the mouse button, the "Symbol Set Properties" dialog box will be displayed. Click the "Appearance" tab and click the "On/off" radio button in the "Type" section, then enter "DO\_0" in the "ON symbol when" text field. Click the "OK" button to save the changes.




**Step 12:** Repeat Steps 10 and 11 to create a second LED object. Use the parameters shown in the image below for this LED object.




**Step 13:** Click the "Text" button and then click a blank area on the page above the left-hand LED object, and enter "DO LED" in the text field.



**Step 14:** After entering the Text, click the text again and the “Text Properties” dialog box will be displayed. Verify that the details in the “Text” field are correct and change the font or other parameter as required, and then click the “OK” button to save the settings.




**Step 15:** Repeat Steps 13 and 14 to create three more Text objects and place them in the appropriate locations. Use the parameters shown in the image below for these Text objects.







**Step 16:** The layout of the page at this stage is shown in the image below. Click and hold the "Number" button and then drag and it onto the page below the "AO Value" text object to create a new number object.




**Step 17:** After releasing the mouse, the "Text Properties" dialog box will be displayed. Click the "Appearance" tab, and click the "Numeric" radio button in the "Type" section. Enter "AO\_0" in the "Numeric expression" field, and set the "Format" to "##.##".




Click the "Input" tab and select the "Keyboard Commands" tab, and then enter "#####ENTER" in the "Key sequence" field. Enter "AO\_0=arg1;" in the "Key sequence command" field, and then click the "OK" button to save the changes.




**Step 18:** Repeat Step 16 to create another new number object and place it below the "AI Value" text object. When the "Text Properties" dialog box for the new Number object is displayed, click the "Appearance" tab. Click the "Numeric" radio button in the "Type" section, then enter "AI\_0" in the "Numeric expression" field, and set the "Format" to "##.##". In this case, there is no need to set the Input parameters, so click the "OK" button to save the changes.




**Step 19:** The layout for the finished page is shown below. Click the "Save" button to save the page.




**Step 20:** In the “Save As” dialog box, enter "page1" in the "Page" field as the name of the page and then click the “OK” button.




**Step 21:** Open the “Citect Explorer” window, and then click the "Computer Setup Wizard" button to open the "Computer Setup Wizard".



**Step 22:** Click the "Express Setup" radio button and then click the "Next >" button to continue.




**Step 23:** Select "Modbus Demo" from the "Project Name" drop-down menu and then click the "Next >" button to continue.







**Step 24:** Click the "Server and Control Client" radio button, and then click the "Next >" button to continue.




**Step 25:** Click the "Stand alone (no other SCADA computers)" radio button and then click the "Next >" button to continue.



**Step 26:** Configure a password for the Server by entering a password in the “Password” text field. Enter the same password in the “Confirm Password” field and then click the “Next >” button to continue.




**Step 27:** Click the "Finish" button to complete the computer setup.





**Step 28:** Press F5 to execute the project. Verify that clicking the "DO Button" button to write DO LED status to on or off. Clicking the AO value "Number object" and enter a value to change the AO Value.



## 3.2. DASyLab

In this section, a detailed description of the procedure for connecting the DASyLab solution to an I-8000-MTCP/ IP-8000-MTCP controller using the Modbus/TCP protocol is presented. In this example, DASyLab version 12 is used. This solution can also be used to request data from external devices such as the ET-7000, I-7188-MTCP, or WISE-7000 using the Modbus protocol.


Before using DASyLab, the controller should be correctly configured using the Modbus Utility. The Net ID is set using the DIP switch located on the right-hand side of the controller (see [Section 2.4 Net ID \(Station Number\) Setting](#) for more information).

### 3.2.1. Adding an Analog Input Channel

**Step 1:** Open the DASyLab application from the Programs Menu.



**Step 2:** Click the "Modules" tab and then expand the "Inputs/Outputs" folder found in the "Modules" folder. Expand the "ModBus" folder and drag an Analog Input object to the worksheet pane on the right-hand side of the window.




**Step 3:** Right-click the object icon and click the “Module Properties” option.




**Step 4:** Configure the object properties in the Modbus Analog Input dialog box using the values shown in the image below.


- A. In the “Interfaces” section, set the Interface to TCP/IP and enter the IP address.
- B. In the “Device” section, select the Address of the controller from the “Address” drop-down menu. This will be the same as the Net ID of the controller.
- C. Check the “Register starts at 0” checkbox.
- D. Select a Register address from the “Register” drop-down menu. The Register address can be found from the AI Mapping table in the Modbus Utility. Select “30” for Analog Input channels. In this demo, the register is set to 30000.
- E. Set the Data Type from the drop-down menu, which is a signed 16-bit integer in this demo.
- F. In the “Data range” section, enable Scaling by checking the “Scaling” checkbox, and set the minimum and maximum values, which are -10 to +10V in this demo.



**Step 5:** Click the “Test” button to verify that the settings are correct, and then click the “OK” button in the Modbus Analog Input dialog box to save the configuration.




The data can also be checked using the “Monitor” function of the Modbus Utility and then clicking the “AI Mapping” tab.



**Step 6:** Click the “Modules” tab and then expand the “Display” folder. Drag an Analog Meter or a List to the worksheet pane on the right-hand side of the window. Drag a line from the “ModBus Ana00” object to the “Analog Dis00” object to establish a connection between the Analog Input, and then drag a line from the line to “List00” to connect these three objects.


Click the “Run” button to connect to the module and begin acquiring data.






### 3.2.2. Adding an Analog Output Channel

**Step 1:** Click the "Modules" tab and then expand the "Inputs/Outputs" folder found in the "Modules" folder. Expand the "ModBus" folder and then drag a Digital Input object to the worksheet pane on the right-hand side of the window.



**Step 2:** Right-click the object icon and click the "Module Properties" option.



**Step 3:** Configure the object properties in the Modbus Analog Output dialog box using the values shown in the image.

A. In the “Interfaces” section, set the Interface to TCP/IP and enter the IP address.


B. In the “Device” section select the Address of the “Address” drop-down menu. This will be the same as the Net ID of the controller.

C. Check the “Register starts at 0” checkbox.


D. Enter the register address, which can be found from the AO Mapping table in the Modbus Utility.

E. Select the Data Type from the drop-down menu, which is a Word unsigned 16-bit integer in this demo.


F. In the “Data range” section, enable Scaling by checking the “Scaling” checkbox, and set the minimum and maximum values, which are -10 to +10V in this demo.





**Step 4:** Click the "Modules" tab and then expand the "Control" folder found in the "Modules" folder. Drag a Slider Control object to the worksheet pane on the right-hand side of the window.




**Step 5:** Right-click the Slider Control icon and click the "Module Properties" option.




**Step 6:** Click the “Scale” button to open the “Scale” dialog box for the slider and set the Begin and End values in the “Display area” section of the “Scale” dialog box. In this demo, -10 to +10 are used. Click the “OK” button to continue.



**Step 7:** Drag a line from the “Slider00” icon to the “ModBus Ana00” icon to establish a connection between the Slider Control and the Analog Output object. Click the “run” button to begin doing output value by the Slider Control.




The value can also be checked using the Modbus Utility.



### 3.2.3. Adding a Digital Input Channel

**Step 1:** Click the "Modules" tab and then expand the "Inputs/Outputs" folder found in the "Modules" folder. Expand the "ModBus" folder and then drag a Digital Input object to the worksheet pane on the right-hand side of the window.




**Step 2:** Right-click the object icon and click the "Module Properties" option.






**Step 3:** Configure the object properties in the Modbus Digital Input dialog box using the values shown in the image below. And then click the “OK” button to set the properties.


- A. In the “Device settings” section, set the Interface to TCP/IP and enter the IP address.
- B. In the “Device settings” section, select the Address of the controller from the “Address” drop-down menu. This will be the same as the Net ID of the controller.
- C. Enter a value for the Start byte, which can be found from the DI Mapping table in the Modbus Utility.




**Step 4:** Click the "Modules" tab and then expand the "Display" folder found in the "Modules" folder. Drag a Status Display object to the worksheet pane on the right-hand side of the window.



**Step 5:** Drag a line from the “Status Dis00” icon to the ”Modbus Dig00” icon to establish a connection between the Status Display object and the Digital Input object. Click the “Run” button to connect to the module and begin acquiring data.




The data can also be checked using the "Monitor" function of the Modbus Utility and then clicking the “DI Mapping” tab.



### 3.2.4. Adding a Digital Output Channel

**Step 1:** Click the "Modules" tab and then expand the "Inputs/Outputs" folder found in the "Modules" folder. Expand the "ModBus" folder and then drag a Digital Output object to the worksheet pane on the right-hand side of the window.




**Step 2:** Right-click the object and click the "Module Properties" option.




**Step 3:** Configure the object properties in the Modbus Digital Output dialog box using the values shown in the image below. And then click the “OK” button to set the properties.

- A. In the “Device settings” section, set the Interface to TCP/IP and enter the IP address.
- B. In the “Device settings” section, select the Address of the controller from the “Address” drop-down menu. This will be the same as the Net ID of the controller.
- C. Enter the Start byte, which can be found from the DO Mapping table in the Modbus Utility.




**Step 4:** Click the "Modules" tab and then expand the "Control" folder found in the "Modules" folder. Drag a Switch Control object to the worksheet pane on the right-hand side of the window.






**Step 5:** Drag a line from the “Switch00” icon to the “Modbus Dig00” icon to establish a connection between the Switch Control object and the Digital Output object. Click the “Run” button to connect to the module and begin exporting data by the Switch00.



The data can also be set on the “DO Mapping” using the “Monitor” function of the Modbus Utility.



### 3.3. EZ Data Logger

In this section, a detailed description of the procedure for connecting the EZ Data Logger solution to a controller using the Modbus/TCP protocol is presented. In this example, EZ Data Logger version 4.5.7 is used.


Before using the EZ Data Logger, the controller should be correctly configured using the Modbus Utility. The Net ID is set using the 8-bit DIP switch located on the right-hand side of the controller (see [Section 2.4 Net ID \(Station number\) Setting](#) for more information).

The EZ Data Logger can be downloaded from:


[http://ftp.icpdas.com/pub/cd/8000cd/napdos/driver/ez\\_data\\_logger/](http://ftp.icpdas.com/pub/cd/8000cd/napdos/driver/ez_data_logger/)

#### 3.3.1. Adding the I/O Modules to the Workgroup


**Step 1:** Open the EZ Data Logger software and the main project window will be displayed containing a default project named “MyProject”.




To create a new project, click the “New Project” item in the “Project” menu.




**Step 2:** Enter a name for the project and click the “Save” button.




**Step 3:** Click the “Group Setup” button in the main toolbar to open the “Workgroup Setting” dialog box, and begin adding the controller and I/O channels to the workgroup list.




**Step 4:** Click the “Install” button in the “Driver List” section to display the “Driver” dialog box.



**Step 5:** Select the “Modbus TCP” option from the “Driver Mode” drop-down menu, and enter the IP address for the controller in the “Host” text field, and then click the “Install” button.





The new driver will be added to the Driver List, as shown below.





**Step 6:** Click the “+Device” button in the “Driver” dialog box to display the “Device” dialog box.




**Step 7:** In the “Select Driver” drop-down menu, select the “MTCP” driver that was added earlier and select “Enter numbers by yourself” from the “Module” drop-down menu.

Enter the name of the Analog Input module, 87017W in this example, in the “Nickname” text field and set the “Slave ID” to “1”.

Check the “3xxxx Input Registers (AI)” checkbox in the “Address Range Definition” section and enter the channel numbers 0 to 7 then select “Integer” as the type.

Click the “Add” button to add the new module configuration to the Device List section and the Channel List section.



Once the new device has been configured, the new channels will be displayed in the “Channel List” section, as shown in the following figure.

Channel List

AI List	AO List	DI List	DO List
Counter List	Freq List	Virtual Channel	Control Logic
Contact List	Web Camera		

Nickname	Tag	Location	Gain	Offset	Hight Alarm	Low Alarm	Description
87017W_30001	87017W_30001	87017W Ch0	1	0	100	-10	30001
87017W_30002	87017W_30002	87017W Ch1	1	0	100	-10	30002
87017W_30003	87017W_30003	87017W Ch2	1	0	100	-10	30003
87017W_30004	87017W_30004	87017W Ch3	1	0	100	-10	30004
87017W_30005	87017W_30005	87017W Ch4	1	0	100	-10	30005
87017W_30006	87017W_30006	87017W Ch5	1	0	100	-10	30006
87017W_30007	87017W_30007	87017W Ch6	1	0	100	-10	30007
87017W_30008	87017W_30008	87017W Ch7	1	0	100	-10	30008

**Step 8:** Repeat the procedure described in Step 6 and 7 to add the details for AO, DI and DO channels to the Channel List using the details illustrated in the images below.

Address Range Definition

0xxx Coils (DO)  [ ] To [ ]

1xxx Discrete Input (DI)  [ ] To [ ]

3xxx Input Registers (AI)  [ ] To [ ] Integer

4xxx Holding Registers (AO)  0 To 7 Integer

Address Range Definition

0xxx Coils (DO)  [ ] To [ ]

1xxx Discrete Input (DI)  0 To 16

3xxx Input Registers (AI)  [ ] To [ ] Integer

4xxx Holding Registers (AO)  [ ] To [ ] Integer

Address Range Definition


0xxx Coils (DO)  0 To 8

1xxx Discrete Input (DI)  [ ] To [ ]

3xxx Input Registers (AI)  [ ] To [ ] Integer

4xxx Holding Registers (AO)  [ ] To [ ] Integer


**Step 9:** The output style for the component and the alarms for a channel can be edited by double-clicking the Nickname of the channel in the Channel List to open the “Modify Channel” dialog box. The example illustrated below uses AI channel 0. The AO, DI and DO channels can be edited in the same way.




Configure the properties for the channel in the “Modify Channel” dialog box.

- To get the Gain and Offset values, enter a Value for Point 1 and Point 2 and then click the “Calculate” button in the “Scaling” section.
- Set the High and Low alarm values in the “Alarm” section. These values will be used to notify the System Administrator of any abnormal events if the “MailNotifier” driver has been enabled. The procedure for enabling the “MailNotifier” function can be downloaded from: [http://ftp.icpdas.com/pub/cd/8000cd/napdos/driver/ez\\_data\\_logger/faq\\_en/ezdl1-003-03\\_how\\_to\\_set\\_alarm\\_notifies\\_by\\_sending\\_email\\_en.pdf](http://ftp.icpdas.com/pub/cd/8000cd/napdos/driver/ez_data_logger/faq_en/ezdl1-003-03_how_to_set_alarm_notifies_by_sending_email_en.pdf)
- Select the desired style to be used for AI channel 0 from the “Component Style” section.
- Click the “Modify” button to save the modified configuration.


**Step 10:** Click the “Workgroup1” entry in the “Work Group” section to highlight it. This ensures that all I/O channels selected later in the procedure will be added to the Channel List for the “Workgroup1”.



**Step 11:** Click the “AI List” button in the “Channel List” section to display the AI channels that were configured earlier. Select all AI channels and then click the “Add>>” button.




After clicking the “Add>>” button, the selected channels will be added to the channel list panel for Workgroup1, as shown in the following figure. These channels will be used for monitoring purposes later.






**Step 12:** Repeat the procedure described in Step 10 and 11 to add the other I/O channels to the channel list for Workgroup1. After all channels have been added, click the “Home” button to return to the main page.




### 3.3.2. Designing the Layout and Acquiring Data

Once the configuration process described in Section 3.3.1 has been completed, the layout of the interface can be adjusted and the data can be acquired.


**Step 1:** To adjust the layout of the interface, click the “Layout” button for “Workgroup1” on the main page of the EZ Data Logger.




**Step 2:** The layout of the interface can be designed by dragging the relevant I/O objects to the desired position on the form. A background image can be added by clicking the “Back Picture” item in the “Picture” menu, or the color of the font can be changed by clicking the “Font Color” menu.




**Step 3:** After the interface design is complete, click the “Hide” menu item to close the design window.



**Step 4:** Click the “Start” button on the main toolbar to establish a connection to the controller and begin acquiring data. Once a connection has been successfully established, the device state indicators will change to “ON” and the connection status messages will be displayed in the yellow message filed.



**Step 5:** To acquire the I/O data, click either of the “Gauge”, “Trend” or “Layout” buttons. In the example illustrated below, the “Layout” button has been clicked, and the values for the relevant modules is displayed interface design window.





# Appendix A: Backing Up and Restoring the EEPROM Settings

The EEPROM is a memory component that is used to store network, system, COM port and module configuration information. The Back Up/Restore functions could be used to restore configuration information for a controller where the data has been lost and can also be used to duplicate EEPROM data from one controller to another.

The size of the EEPROM is different in every controller and each block in the EEPROM stores different types of data. The following table provides an overview of the writable blocks and the reserved blocks. The writable blocks contains information related to the library version, COM port configuration, watchdog timer, module settings, and the reserved blocks contains details of the IP address, Mask, Gateway and MAC address.

Controller	Writable Blocks	Reserved Blocks	Number of Blocks
I-8000	1-7	0	8 (blocks 0-7)
IP-8000	8-14	0-7	64 (blocks 0-63)
7188E	1-7	0	8 (blocks 0-7)

**Note 1:** Before attempting to read or write EEPROM data, ensure that the version number of the I/O Scan Library is 1.6.0 or later.

**Note 2:** This function only supports connections via the COM port. Before attempting to perform this function, ensure that COM1 on the controller is connected to the computer.



## 1. Backing up the Settings


**Step 1:** Reboot the controller in INIT mode.

For I-8000 modules, short the INIT\* and INIT\*COM pins.


For IP-8000 modules, move the DIP switch to the “Init” position.

For 7188E devices, short the INIT\* and GND pins.


**Step 2:** Execute the Modbus Utility and select Modbus/TCP controller mode.




**Step 3:** Select the “Update Firmware” option from the “Client Tools” menu to connect to the controller.




Select the COM port from the drop-down menu and then click the “Connect” button. Once a connection is established, the “Back up Settings” and “Restore Settings” buttons will be displayed.



**Step 4:** Click the “Back up Settings” button and the “Back up EEPROM file” dialog box will be displayed. Click the “Save” button to save the current configuration of the controller to the default root folder named “backup\_setting”. The status message “Downloading. Please wait...” will be displayed while the file is being saved.



Once the download is complete, a message will be displayed to notify that the file was saved successfully. Click the "OK" button to continue.



## 2. Restoring the Settings


**Step 1:** Reboot the controller in INIT mode.

For I-8000 modules, short the INIT\* and INIT\*COM pins.


For IP-8000 modules, move the DIP switch to the “Init” position.

For 7188E devices, short the INIT\* and GND pins.


**Step 2:** Execute the Modbus Utility and select the Modbus/TCP controller mode.




**Step 3:** Select the “Update Firmware” option from the “Client Tools” menu to connect to the controller.




Select the COM port from the drop-down menu and then click the “Connect” button. Once a connection is established, the “Back up Settings” and “Restore Settings” buttons will be displayed.




**Step 4:** To configure a controller to the same settings as another, click the “Recover Settings” button and the “Select an EEPROM file to Restore” dialog box will be displayed. Click the name of the file that contains the configuration to be uploaded, and then select the blocks to be duplicated from the “Write Block” drop-down menus. Click the “Write 1/multi-block” button to write the configuration to the EEPROM.



The status message "Writing. Please wait..." will be displayed while the configuration is being duplicated.



Once the duplication process is complete, a message will be displayed to notify that the file was written successfully. Click the "OK" button to continue.





## Appendix B: Function Codes (FC)

All data addresses in a Modbus message **start at zero** and are transmitted in **hexadecimal** format. For example:

- A. Input register 30001 is addressed as 0 in the data address field of the Modbus message.
- B. Coil 24 (decimal) in an I/O module is addressed as coil 0017 (hexadecimal) in the Modbus message (Equivalent to 23 in decimal).

As the function code already specifies whether the operation is DO, DI, AO or AI, the references '0xxxx, 1xxxx, 4xxxx, 3xxxx' are implicit. Function codes are used in both the Modbus RTU Master Tool and the Modbus TCP Client Tool.

## 1. Read DO (0xxxx)

### Function Code 01=Read Coil Status

Request						
Byte	0	1	2	3	4	5
	Net ID	FC=01	Starting Address		Bit Count	
Example: Net ID = 20 <sup>(*1)</sup> , Read Coils 18-30 <sup>(*2)</sup>	Hex	14	1	0	11	0 D
	Command		14 1 0 11 0 D			
Response						
Byte	0	1	2	3	~Byte Count+2	
	Net ID	FC=01	Byte Count	Bits Values		
Response	14	01	2 <sup>(*3)</sup>	5C (Coils 25-18)		1B (Coils 30-26)
Binary				0101 1100 <sup>(*4)</sup>		0001 1011 <sup>(*5)</sup>

\*1: Net ID decimal 20 = hexadecimal 14.

\*2: Coils 18-30 are addressed as 17-29 (decimal), with a total of 13 coils in Modbus.

\*3: If the number of coils returned isn't a multiple of 8, the remaining bits in the last byte will be filled with 0.

\*4: 5C= 0101 1100 refers to coils 18 to 25 (from right to left). The status values are: OFF (25), ON (24), OFF (23), ON (22), ON (21), ON (20), OFF (19), OFF (18).

\*5: 1B= 0001 1011, refers to coils 26 to 30 (from right to left). The status values are: ON (30), ON (29), OFF (28), ON (27), ON (26).

## 2. Read DI (1xxxx)

### Function Code 02=Read Input Status

Request							
Byte		0	1	2	3	4	5
		Net ID	FC=02	Starting Address		Bit Count	
Example: Net ID = 1, Read the status of inputs 1-8(*1)	Hex	1	2	0	0	0	8
	Command		1 2 0 0 0 8				
Response							
Byte	0	1	2	3	~Byte Count+2		
	Net ID	FC=02	Byte Count	Bits Values			
Response	1	2	1	FF (Coils 8-1)			
Binary				1111 1111(*2)			

\*1: Inputs 1-8 are addressed as 0-7 (decimal), there are a total of 8 inputs.

\*2: FF=1111 1111, refers to coils 8 to 1 (from right to left), and the status of each coil is set to ON.

### 3. Read AO (4xxxx)

#### Function Code 03=Read Holding Registers

Request							
Byte		0	1	2	3	4	5
		Net ID	FC=03	Starting Address		Word Count	
Example: Net ID = 25, Read registers 40027-40028(*1)	Hex	19	3	0	1A	0	2
	Command		19 3 0 1A 0 2				
Response							
Byte	0	1	2	3		~Byte Count+2	
	Net ID	FC=03	Byte Count	Register Values			
Response	19	3	4	2	17	0	C8
Register				40027(*2)		40028(*2)	

\*1: Holding registers 40027-40028 are addressed as 26-27 in Modbus.

\*2: The value of register 40027 is shown as a 2-byte value: 02 17 (hexadecimal) = 535 (decimal), the value of register 40028 is 00 C8 (hexadecimal) = 200 (decimal). For details of how to convert these values to float format, see [Appendix C: Range Codes for Analog Modules](#).

## 4. Read AI (3xxxx)

### Function Code 04=Read Input Registers

Request							
Byte		0	1	2	3	4	5
		Net ID	FC=04	Starting Address		Word Count	
Example: Net ID = 2, Read registers 30001-30002(*1)	Hex	2	4	0	0	0	2
	Command	2 4 0 0 0 2					
Response							
Byte	0	1	2	3	~Byte Count+2		
	Net ID	FC=04	Byte Count	Register Values			
Response	2	4	4	0	0	0	64
Register				30001(*2)		30002(*2)	

\*1: Input registers 30001-30002 are addressed as 0-1 in Modbus.

\*2: The value of register 30001 is shown as a 2-byte value: 00 00 (hexadecimal) = 0 (decimal), the value of register 30002 is 00 64 (hexadecimal) = 100 (decimal). For details of how to convert these values to float format, see [Appendix C: Range Codes for Analog Modules](#).

## 5. Write Single DO (0xxxx)

### Function Code 05=Write Single Coil

Request						
Byte	0	1	2	3	4	5
	Net ID	FC=05	Write Address		FF 00=ON, 00 00=OFF	
Example: Net ID = 1, set coil 5 to ON(*1)	Hex	1	5	0	4	FF 0
	Command	1 5 0 4 FF 0				
Response						
Byte	0	1	2	3	4	5
	Net ID	FC=05	Write Address		FF 00=ON, 00 00=OFF	
Response	1	5	0	4	FF	0
If the request is successful, the function will return an echo of the request.						

\*1: Coil 5 is addressed as 4 in Modbus.

A value of FF 00 sets the coil to ON, and a value of 00 00 sets it to OFF. All other values are treated as invalid.



## 6. Write Single AO (4xxxx)

### Function Code 06= Write Single Register

Request						
Byte	0	1	2	3	4	5
	Net ID	FC=06	Write Address		Register Value	
Example: Net ID = 1, set register 40003 <sup>(*1)</sup> to 155 <sup>(*2)</sup>	Hex	1	6	0	2	0 9B
	Command		1 6 0 2 0 9B			
Response						
Byte	0	1	2	3	4	5
	Net ID	FC=06	Write Address		Register Value	
Response	1	6	0	4	0	9B
If the request is successful, the function will return an echo of the request.						

\*1: Register 40003 is addressed as 2 in Modbus.

\*2: Register value 155 = 9B (hexadecimal).

## 7. Write DO (0xxxx)

### Function Code 15=Write Multiple Coils

Request										
Byte	0	1	2	3	4	5	6	7	~Byte Count+6	
	Net ID	FC=15	Write Address		Bit Count		Byte Count	Data to be Written		
Hex	1	F	0	0	0	C	2	FE <sup>(*2)</sup>	05 <sup>(*2)</sup>	
Example: Net ID = 1, write coils 1 to 12 <sup>(*1)</sup>								1111	0000	
								1110	0101	
Command			1 F 0 0 0 C 2 FE 5							
Response										
Byte	0	1	2	3	4	5				
	Net ID	FC=15	Write Address		Bit Count					
Response	1	F	0	0	0	0	C			

\*1: Coils 1-12 are addressed as 0-11, there are a total of 12 (hexadecimal 0C) coils in Modbus.

\*2: The data is a 2-byte value. FE 05 (hexadecimal) = 1111 1110 0000 0101 (binary)

Bit	1	1	1	1	1	1	1	0	0	0	0	0	1	0	1
Coil	8	7	6	5	4	3	2	1	-	-	-	-	12	11	10 9

## 8. Write AO (4xxxx)

### Function Code 16= Write Multiple Registers

Request											
Byte	0	1	2	3	4	5	6	7	~Byte Count+6		
	Net ID	FC=16	Write Address		Word Count		Byte Count	Register Values			
Hex	1	10	0	0	0	2	4	0	19	0	64
Example: Net ID = 1, write registers 40001-40002 <sup>(*1)</sup>				Command		1 10 0 0 0 2 4 0 19 0 64					
Response											
Byte	0	1	2	3	4	5					
	Net ID	FC=16	Write Address		Word Count						
Response	1	10	0	0	0	2					


\*1: Registers 40001-40002 are addressed as 0-1 in Modbus.

The value of register 40001 is 25 (hexadecimal 19), the value of register 40002 is 100 (hexadecimal 64).

# Appendix C: Range Codes for Analog Modules

The Modbus Utility can be used to convert the input or output value to float format or other formats. An example of the operation can be seen in step 2 of [2.14 Monitoring](#).

The formula shown below provides details of the conversion process.



Display Value  $Y = (\text{Gain} * \text{Memory Value } X) + \text{Offset}$

Gain =  $\frac{Y_1 - Y_2}{X_1 - X_2}$ , the Slope for this Range Code type. (In the above illustration, the output range is 4 to 20mA.)

Memory Value  $X$  = the input or output memory value.

Offset =  $Y_2 - (X_2 * \text{Gain})$ , the offset value to compensate for any inaccuracies in the module.

Use I-87028W as an example, the Range code set to 31 (4-20mA), and the output memory value is 2048. What's the display value?

Step1. Calculate the Gain value. Gain =  $(20-4) / (32767-0) = 0.000488296$

Step2. Calculate the Offset value. Offset =  $4 - (0 * 0.000488296) = 4$

Step3. Calculate the display value. Display Value  $Y = (0.000488296 * 2048) + 4 = 5$  mA.

The following tables provide the maximum and minimum values, the Gain, and the Offset for each range code type.

- 87K Analog Modules
  - Current and Voltage Type Definitions
  - Thermocouple Type Definitions
  - RTD (Resistance Temperature Detector) Type Definitions
  - Thermistor Type Definitions
- 8K Modules

## 1. 87K Analog Modules

### 1.1. Current and Voltage Type Definitions

Type Code	Type Definitions	Data Format	Max. Value	Min. Value	Gain	Offset
<b>Analog Input Modules</b>						
00	-15 mV to +15 mV	Input Range	+15.0 mV	-15.0 mV	0.00030518	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
01	-50 mV to +50 mV	Input Range	+50.0 mV	-50.0 mV	0.001525902	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
02	-100 mV to +100 mV	Input Range	+100.0 mV	-100.0 mV	0.003051804	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
03	-500 mV to +500 mV	Input Range	+500.0 mV	-500.0 mV	0.015259022	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
04	-1 V to +1V	Input Range	+1.0 V	-1.0 V	0.000030518	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
05	-2.5 V to +2.5 V	Input Range	+2.5V	-2.5V	0.025	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
06*1	-20 mA to +20 mA	Input Range	+20.0 mA	-20.0 mA	0.00061036	0
		Decimal Units	+32767	-32768		

Type Code	Type Definitions	Data Format	Max. Value	Min. Value	Gain	Offset
	(With 125 ohms resistor)	2's Complement Hexadecimal Units	7FFF	8000		
07*2	+4 mA to +20 mA	Input Range	+20.0 mA	+4.0 mA	0.00024414	+4
		Decimal Units	+65535	+0		
		2's Complement Hexadecimal Units	FFFF	0000		
08	-10 V to +10 V	Input Range	+10.0 V	-10.0 V	0.00030518	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
09	-5 V to +5 V	Input Range	+5.0 V	-5.0 V	0.00015259	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
0A	-1 V to +1V	Input Range	+1.0 V	-1.0 V	0.000030518	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
0B	-500 mV to +500 mV	Input Range	+500.0 mV	-500.0 mV	0.015259022	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
0C	-150 mV to +150 mV	Input Range	+150.0 mV	-150.0 mV	0.004577706	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
0D*3	-20 mA to +20 mA (with 125 ohm resistor)	Input Range	+20.0 mA	-20.0 mA	0.00061036	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		



Type Code	Type Definitions	Data Format	Max. Value	Min. Value	Gain	Offset
1A*2	+0 mA to +20 mA	Input Range	+20.0 mA	+0.0 mA	0.00030518	0
		Decimal Units	+65535	+0		
		2's Complement Hexadecimal Units	FFFF	0000		
1B	-150 V to +150 V	Input Range	+150.0 V	-150.0 V	0.0045777	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
1C	-50 V to +50 V	Input Range	+50.0 V	-50.0 V	0.0015259	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
<b>Digital Input/Output, Counter, Frequency, Encoder Modules</b>						
40	Digital Input/Output	N/A	N/A	N/A	N/A	N/A
50	Counter Mode	N/A	N/A	N/A	N/A	N/A
51	Frequency Mode	N/A	N/A	N/A	N/A	N/A
54	Up/Down Counter Mode	N/A	N/A	N/A	N/A	N/A
55	Pulse Mode	N/A	N/A	N/A	N/A	N/A
56	AB Phase Mode	N/A	N/A	N/A	N/A	N/A
<b>Analog Output Modules</b>						
0, 30	+0 mA to +20 mA	Output Range	+20.0 mA	+0.0 mA	0.00061037	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		

Type Code	Type Definitions	Data Format	Max. Value	Min. Value	Gain	Offset
		Gain <sup>-1</sup> = 1638.35				
1, 31	+4 mA to +20 mA	Output Range	+20.0 mA	+4.0 mA	0.000488296	+4
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Gain <sup>-1</sup> = 2047.9375				
2, 32	+0 V to +10 V	Output Range	+10.0 V	+0.0 V	0.000305185	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Gain <sup>-1</sup> = 3276.7				
3, 33	-10 V to +10 V	Output Range	+10.0 V	-10.0 V	0.00030518	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
		Gain <sup>-1</sup> = 3276.75				
4, 34	+0 V to +5 V	Output Range	+5.0 V	+0.0 V	0.00015259	0
		Decimal Units	+32767	0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Gain <sup>-1</sup> = 6553.4				
5, 35	-5 V to +5 V	Output Range	+5.0 V	-5.0 V	0.00015259	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
		Gain <sup>-1</sup> = 6553.4				
6, 36	+0 V to +20 V	Output Range	+20.0 V	+0.0 V	0.00061037	0
		Decimal Units	+32767	0		
		2's Complement Hexadecimal Units	7FFF	0000		

Type Code	Type Definitions	Data Format	Max. Value	Min. Value	Gain	Offset
		Gain <sup>-1</sup> = 1638.35				
<p>Notes</p> <p>*1: When I-87018 and I-87018R are connecting to a current source set to the 06 type code, an optional external 125 Ohms resistor is required.</p> <p>*2: I-87017RC has built-in 125 Ohms resistors for each channel. When connecting to a current source, no add any external resistors required.</p> <p>*3: When I-87017 and I-87017R are connecting to a current source set to 0D type code, an optional external 125 Ohms resistor is required. On the other hand, I-87017RC has built-in 125 Ohms resistors for each channel, so require no external resistors.</p>						

## 1.2. Thermocouple Type Definitions

Type Code	Thermocouple Type	Data Format	Max. Value	Min. Value	Gain	Offset
0E	J Type	Input Range (Celsius)	+760.0	-210.0	0.023194089	0
		Decimal Units	+32767	-9054		
		2's Complement Hexadecimal Units	7FFF	DCA2		
0F	K Type	Input Range (Celsius)	+1372.0	-270.0	0.0418717327	0
		Engineer Units	+32767	-6448		
		2's Complement Hexadecimal Units	7FFF	E6D0		
10	T Type	Input Range (Celsius)	+400.0	-270.0	0.0122073426	0
		Decimal Units	+32767	-22118		
		2's Complement Hexadecimal Units	7FFF	A99A		
11	E Type	Input Range (Celsius)	+1000.0	-270.0	0.030518575	0
		Decimal Units	+32767	-8847		
		2's Complement Hexadecimal Units	7FFF	DD71		
12	R Type	Input Range (Celsius)	+1768.0	+0.0	0.0539567247	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
13	S Type	Input Range (Celsius)	+1768.0	+0.0	0.0539567247	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		

Type Code	Thermocouple Type	Data Format	Max. Value	Min. Value	Gain	Offset
14	B Type	Input Range (Celsius)	+1820.0	+0.0	0.0555436872	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
15	N Type	Input Range (Celsius)	+1300.0	-270.0	0.0396745173	0
		Decimal Units	+32767	-6805		
		2's Complement Hexadecimal Units	7FFF	E56B		
16	C Type	Input Range (Celsius)	+2320.0	+0.0	0.0708029419	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
17	L Type	Input Range (Celsius)	+800.0	-200.0	0.0244146585	0
		Decimal Units	+32767	-8192		
		2's Complement Hexadecimal Units	7FFF	E000		
18	M Type	Input Range (Celsius)	+100.0	-200.0	0.0061035156	0
		Decimal Units	+16384	-32768		
		2's Complement Hexadecimal Units	4000	8000		
19	L Type DIN43710	Input Range (Celsius)	+900.0	-200.0	0.0274670395	0
		Decimal Units	+32767	-7281		
		2's Complement Hexadecimal Units	7FFF	E38F		

### 1.3. RTD (Resistance Temperature Detector) Type Definitions

Type Code	RTD Type	Data Format	Max. Value	Min. Value	Gain	Offset
20	Platinum 100 a = 0.00385 -100°C to 100°C	Input Range (Celsius)	+100.0	-100.0	0.0030518043	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
		Ohm	+138.5	+60.25		
21	Platinum 100 a = 0.00385 0°C to 100°C	Input Range (Celsius)	+100.0	+0.0	0.0030518509	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+138.5	+100.0		
22	Platinum 100 a = 0.00385 0°C to 200°C	Input Range (Celsius)	+200.0	+0.0	0.0061037018	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+175.84	+100.0		
23	Platinum 100 a = 0.00385 0°C to 600°C	Input Range (Celsius)	+600.0	+0.0	0.0183111056	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+313.59	+100.0		
24	Platinum 100 a = 0.003916 -100°C to 100°C	Input Range (Celsius)	+100.0	-100.0	0.0030518043	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
		Ohm	+139.16	+59.58		

Type Code	RTD Type	Data Format	Max. Value	Min. Value	Gain	Offset
25	Platinum 100 a = 0.003916 0°C to 100°C	Input Range (Celsius)	+100.0	+0.0	0.0030518509	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+139.16	+100.0		
26	Platinum 100 a = 0.003916 0°C to 200°C	Input Range (Celsius)	+200.0	+0.0	0.0061037018	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+177.13	+100.0		
27	Platinum 100 a = 0.003916 0°C to 600°C	Input Range (Celsius)	+600.0	+0.0	0.01831110568	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+317.28	+100.0		
28	Nickel 120 -80°C to 100°C	Input Range (Celsius)	+100.0	-80.0	0.0030518302	0
		Decimal Units	+32767	-26214		
		2's Complement Hexadecimal Units	7FFF	999A		
		Ohm	+200.64	+120.6		
29	Nickel 120 0°C to 100°C	Input Range (Celsius)	+100.0	+0.0	0.0030518509	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+200.64	+120.6		
2A	Platinum	Input Range	+600.0	-200.0	0.0183112453	0



Type Code	RTD Type	Data Format	Max. Value	Min. Value	Gain	Offset
	1000 a =0.00385 -200°C to 600°C	(Celsius)				
		Decimal Units	+32767	-10922		
		2's Complement Hexadecimal Units	7FFF	D556		
		Ohm	+3137.1	+185.2		
2B*1	Cu 100 a =0.00421 -20°C to 150°C	Input Range (Celsius)	+150.0	-20.0	0.0045777	0
		Decimal Units	+32767	-4369		
		2's Complement Hexadecimal Units	7FFF	EEEE		
		Ohm	+163.17	+91.56		
2C*1	Cu 100 a =0.00421 0°C to 200°C	Input Range (Celsius)	+200.0	+0.0	0.0061037	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+167.75	+90.34		
2D*1	Cu 1000 a =0.00421 -20°C to 150°C	Input Range (Celsius)	+150.0	-20.0	0.0045777	0
		Decimal Units	+32767	-4369		
		2's Complement Hexadecimal Units	7FFF	EEEE		
		Ohm	+1631.7	+915.6		
2E*2	Pt 100 a =0.00385 -200°C to 200°C	Input Range (Celsius)	+200.0	-200.0	0.0061036	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
		Ohm	+175.84	+18.49		
2F*2	Pt 100 a	Input Range (Celsius)	+200.0	-200.0	0.0061036	0

Type Code	RTD Type	Data Format	Max. Value	Min. Value	Gain	Offset
	=0.003916 -200°C to 200°C	Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
		Ohm	+177.14	+17.14		
80*2	Pt 100 a =0.00385 -200°C to 600°C	<b>Input Range (Celsius)</b>	<b>+600.0</b>	<b>-200.0</b>	<b>0.018311</b>	<b>0</b>
		Decimal Units	+32767	-10922		
		2's Complement Hexadecimal Units	7FFF	D556		
		Ohm	+313.59	+18.49		
81*2	Pt 100 a =0.003916 -200°C to 600°C	<b>Input Range (Celsius)</b>	<b>+600.0</b>	<b>-200.0</b>	<b>0.018311</b>	<b>0</b>
		Decimal Units	+32767	-10922		
		2's Complement Hexadecimal Units	7FFF	D556		
		Ohm	+317.28	+17.14		

**Notes**

\*1: Type code 2B, 2C and 2D are only available with I-87015.

\*2: Type code 2E, 2F, 80 and 81 are only available with the I-87015 firmware version A1.10 and later, I-87013 firmware version B1.3 and later.

## 1.4. Thermistor Type Definitions

Type Code	Thermistor Type	Data Format	Max. Value	Min. Value	Gain	Offset
60	Precon ST-A3 -30 to 240 degree Fahrenheit	Input Range (Fahrenheit)	+240.0	-30.0	0.0073244	0
		Decimal Units	+32767	-4096		
		2's Complement Hexadecimal Units	7FFF	F000		
		Ohm	+539.4	+173600.0		
61	Type U Fenwell -50 to 150 degree Celsius	Input Range (Celsius)	+150.0	-50.0	0.004577	0
		Decimal Units	+32767	-10922		
		2's Complement Hexadecimal Units	7FFF	D556		
		Ohm	+37.2	+134020.0		
62	Type U Fenwell 0 to 150 degree Celsius	Input Range (Celsius)	+150.0	+0.0	0.004577	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Ohm	+37.2	+6530.0		
63	YSI L Mix 100	Input Range (Celsius)	+100.0	-80.0	0.0030518	0
		Decimal Units	+32767	-26214		
		2's Complement Hexadecimal Units	7FFF	999A		
		Ohm	+14.3	+14470.0		
64	YSI L Mix 300	Input Range	+100.0	-80.0	0.0030518	0
		Decimal Units	+32767	-26214		
		2's Complement Hexadecimal Units	7FFF	999A		
		Ohm	+35.8	+67660.0		

Type Code	Thermistor Type	Data Format	Max. Value	Min. Value	Gain	Offset
65	YSI L Mix 1000	Input Range (Celsius)	+100.0	-70.0	0.00305	0
		Decimal Units	+32767	-22937		
		2's Complement Hexadecimal Units	7FFF	A667		
		Ohm	+106.4	+132600.0		
66	YSI B Mix 2252	Input Range (Celsius)	+150.0	-50.0	0.004577	0
		Decimal Units	+32767	-10922		
		2's Complement Hexadecimal Units	7FFF	D556		
		Ohm	+41.8	+151000.0		
67	YSI B Mix 3000	Input Range (Celsius)	+150.0	-40.0	0.004577	0
		Decimal Units	+32767	-8738		
		2's Complement Hexadecimal Units	7FFF	DDDE		
		Ohm	+55.6	+101000.0		
68	YSI B Mix 5000	Input Range (Celsius)	+150.0	-40.0	0.004577	0
		Decimal Units	+32767	-8738		
		2's Complement Hexadecimal Units	7FFF	DDDE		
		Ohm	+92.7	+168300.0		
69	YSI B Mix 6000	Input Range (Celsius)	+150.0	-30.0	0.004577	0
		Decimal Units	+32767	-6553		
		2's Complement Hexadecimal Units	7FFF	E667		
		Ohm	+111.5	+106200.0		
6A	YSI B Mix	Input Range	+150.0	-30.0	0.004577	0

Type Code	Thermistor Type	Data Format	Max. Value	Min. Value	Gain	Offset
	10K	(Celsius)				
		Decimal Units	+32767	-6553		
		2's Complement Hexadecimal Units	7FFF	E667		
		Ohm	+185.9	+177000.0		
6B	YSI H Mix 10K	Input Range (Celsius)	+150.0	-30.0	0.004577	0
		Decimal Units	+32767	-6553		
		2's Complement Hexadecimal Units	7FFF	E667		
		Ohm	+237.0	+135200.0		
6C	YSI H Mix 30K	Input Range (Celsius)	+200.0	-10.0	0.0061037	0
		Decimal Units	+32767	-1638		
		2's Complement Hexadecimal Units	7FFF	F99A		
		Ohm	+186.7	+158000.0		
70-77	User-defined -50 to 150 degree Celsius	Input Range (Celsius)	+150.0	-50.0	0.004577	0
		Decimal Units	+32767	-10922		
		2's Complement Hexadecimal Units	7FFF	D556		
		Ohm	+0.0	+0.0		

## 2. 8K Modules

Type Code	Type Definitions	Data Format	Max. Value	Min. Value	Gain	Offset
05	-2.5 V to +2.5 V	Input Range	+2.5 V	-2.5 V	0.000076295	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
06	-20 mV to +20 mV	Input Range	+20.0 mV	-20.0 mV	0.00061036	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
07	-1.25 V to +1.25 V	Input Range	+1.25 V	-1.25 V	0.000038147	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
08	-10 V to +10 V	Input Range	+10.0 V	-10.0 V	0.00030518	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
09	-5 V to +5 V	Input Range	+5.0 V	-5.0 V	0.00015259	0
		Decimal Units	+32767	-32768		
		2's Complement Hexadecimal Units	7FFF	8000		
30	+0 mA to +20 mA	Output Range	+20.0 mA	+0.0 mA	0.00061037	0
		Decimal Units	+32767	+0		
		2's Complement Hexadecimal Units	7FFF	0000		
		Gain <sup>-1</sup> = 1638.35				
33	-10 V to +10 V	Output Range	+10.0 V	-10.0 V	0.00030518	0
		Decimal Units	+32767	-32768		
		2's Complement	7FFF	8000		

Type Code	Type Definitions	Data Format	Max. Value	Min. Value	Gain	Offset
		Hexadecimal Units				
		Gain <sup>-1</sup> = 3276.75				
80	Mode 0: Pulse/ Direction Counter	Decimal Units	+2147483 647	-2147483 648	1	0
		2's Complement Hexadecimal Units	7FFFFFFF	80000000		
	Mode 1: Up/Down Counter	Decimal Units	+2147483 647	-2147483 648	1	0
		2's Complement Hexadecimal Units	7FFFFFFF	80000000		
	Mode 2: Frequency	Decimal Units	450000	0	1	0
		2's Complement Hexadecimal Units	6DDD0	00000000		
	Mode 3: Up Counter	Decimal Units	+4294967 295	0	1	0
		2's Complement Hexadecimal Units	FFFFFFFF	00000000		