

SC-6104-W5

User Manual

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning!

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2015 ICP DAS Co., Ltd. All rights are reserved.

Trademarks

Names are used for identification purposes only and may be registered trademarks of their respective companies.

Contents

| | |
|---|-----------|
| 1. Introduction..... | 4 |
| 2. Hardware Information..... | 6 |
| 2.1. IO Specifications | 6 |
| 2.2. System Specifications | 7 |
| 2.3. Pin Assignments..... | 8 |
| 2.4. Wire Connections..... | 9 |
| 2.5. DIP Switch and Rotary Switch Configuration | 11 |
| 2.5.1. INIT Mode..... | 12 |
| 2.5.2. Hardware Configuration Mode..... | 13 |
| 2.5.3. Software Configuration Mode | 13 |
| 2.6. Software Configuration Tables | 14 |
| 3. DCON Protocol..... | 15 |
| 3.1. %aannttccff | 18 |
| 3.2. \$aa2 | 20 |
| 3.3. \$aa5 | 22 |
| 3.4. \$aa6 | 24 |
| 3.5. \$aaF..... | 26 |
| 3.6. \$aaLC0n | 27 |
| 3.7. \$aaLC1 | 29 |
| 3.8. \$aaLC2nnnn | 30 |
| 3.9. \$aaLC3 | 32 |
| 3.10. \$aaM | 34 |
| 3.11. \$aaP..... | 35 |
| 3.12. \$aaPc | 37 |
| 3.13. #aa | 39 |
| 3.14. @aa..... | 40 |
| 3.15. @aah..... | 42 |
| 3.16. @aaDI | 43 |
| 3.17. @aaDOhh | 44 |
| 3.18. @aaA2CjToo | 45 |
| 3.19. @aaA3Cj..... | 47 |
| 3.20. ~** | 48 |
| 3.21. ~aa0 | 49 |
| 3.22. ~aa1 | 50 |
| 3.23. ~aa2 | 51 |
| 3.24. ~aa3ehh | 52 |
| 3.25. ~aa4 | 53 |

| | | |
|-----------|---|-----------|
| 3.26. | ~aa4P | 54 |
| 3.27. | ~aa4S | 55 |
| 3.28. | ~aa5ppss | 56 |
| 3.29. | ~aa5P | 57 |
| 3.30. | ~aa5S | 58 |
| 3.31. | ~aaD | 59 |
| 3.32. | ~aaDt | 60 |
| 3.33. | ~aaRS | 61 |
| 3.34. | ~aaRD | 62 |
| 3.35. | ~aaRDhh | 63 |
| 4. | Modbus RTU Protocol | 64 |
| 4.1. | Modbus Address Mapping | 65 |
| 4.2. | Function 01 - Read Coils | 67 |
| 4.3. | Function 02 - Read Discrete Inputs | 68 |
| 4.4. | Function 03 - Read Multiple Registers | 69 |
| 4.5. | Function 04 - Read Multiple Input Registers | 70 |
| 4.6. | Function 05 – Write Single Coil | 71 |
| 4.7. | Function 06 – Write Single Register | 72 |
| 4.8. | Function 15 – Write Multiple Coils | 73 |
| 4.9. | Function 16 – Write Multiple Registers | 74 |
| 4.10. | Function 70 – Read/Write Module Setting | 75 |
| 4.10.1. | Sub-function 00 – Read Module Name | 76 |
| 4.10.2. | Sub-function 04 – Write Module Address | 77 |
| 4.10.3. | Sub-function 05 – Read Communication Setting | 78 |
| 4.10.4. | Sub-function 06 – Write Communication Setting | 79 |
| 4.10.5. | Sub-function 32 – Read Firmware Version | 80 |
| 4.10.6. | Sub-function 39 – Write Power-on Value | 81 |
| 4.10.7. | Sub-function 40 – Read Power-on Value | 82 |
| 4.10.8. | Sub-function 53 – Set Response Delay Time | 83 |
| 4.10.9. | Sub-function 54 – Read Response Delay Time | 84 |

1. Introduction

The SC-6104-W5 is an easy-to-use smart control module. It can be used in such as FCU control system and lighting control system. SC-6104-W5 requires no specialist skills to install and operate, and no software is needed in order to control the Digital Output channel.



The SC-6104-W5 provides 1 channel for Digital Input (photocouple isolation), 4 channels for relay output and 1 channel for temperature sensor (thermistor). The output channels are 4 Form C type relay, while the input channel is based on a sink-type using a wire connection. The input channel can be used to directly control the 4 channels relay ON and OFF sequence without requiring a remote host controller. And the SC-6104-W5 support 7 kinds coordinated function for users select. 4 kV ESD protection and 5000 Vrms intra-module isolation are also provided.

When required, communication with the SC-6104-W5 is programmable based on either the DCON or the Modbus RTU protocol, and an added benefit is that different addresses can be set for DCON or Modbus RTU communication via hardware or software configuration.

Warning

Don't connect SC-6104-W5 with any device where the loading is greater than 550 W (5A, 110V) per channel, as this may cause the module to malfunction.

Features

- Cost-effective for Lighting control and FCU control module
- Power Relay Outputs
- Isolated AC Digital Input
- Support 7 kinds AC DI Input Direct Control Relay ON/OFF Function
- 1 Channel Thermistor Temperature Sensor (-40°C ~ +80°C)
- Easy installation
- Use fireproof materials (UL94-V0 Level)
- Low power consumption
- Support Modbus RTU and DCON Protocol
- Two RJ-11 Connector (**6P4C or 6P6C**), Quick and easy wiring

2. Hardware Information


2.1. IO Specifications

| Digital Input | |
|--------------------------------|---|
| Input Channel | 1 |
| Type | 90 ~ 240 V _{AC} |
| On Voltage Level | 85 V _{AC} |
| Off Voltage Level | 60 V _{AC} |
| Input Impedance | 68 kΩ, 1 W |
| Isolation | 5000 V _{rms} |
| Function | Local and remote direct control relay ON/OFF and remote status monitoring. |
| Digital Output | |
| Output Channel | 4 |
| Type | Power Relay, 4 Form C |
| Operating Voltage | 250 V _{AC} or 30 V _{DC} |
| Max. Load Current | 20 A (NO) / 16 A (NC) @ 250 V _{AC} (Recommend Working Current 5 A) |
| Operating Time | 20 ms Max. |
| Release Time | 10 ms Max. |
| Electrical Life (1800 ops/hr) | 100,000 ops |
| Mechanical Life (18000 ops/hr) | 10,000,000 ops |
| Power-on & Safe Value | Yes, Programmable |
| Temperature Sensor | |
| Temperature Channel | 1 |
| Type | Thermistor |
| Operating Temperature Range | -40°C ~ +80°C |
| Temperature Tolerance | ±2°C |


2.2. System Specifications

| Communication | |
|---------------------------|---|
| Interface | RS-485 |
| Data Format | N,8,1 / O,8,1 / E,8,1 / N,8,2 |
| Baud Rate | Hardware Configuration: Fixed 9600 bps |
| | Software Configuration: 1200 ~ 115200 bps |
| Protocol | Modbus RTU or DCON |
| Node Address | 128 ~ 159 for hardware configuration 0 ~ 255 for software configuration * For Modbus RTU, address 0 is auto become to 1 |
| Connector | RJ-11 (6P4C or 6P6C) / 4-pin screw terminal |
| LED Indicators | |
| Power | 1 LED as power indicator |
| Digital Output | 4 LED as digital output indicator |
| EMS Protection | |
| ESD | ±4 kV contact for each terminal |
| EFT | ±1 kV for power and communication |
| Power Requirements | |
| Input Voltage Range | +10 ~ +30 V _{DC} |
| Consumption | 100 mA @ 24 V _{DC} (2.4 W Max.) |
| Connector | RJ-11 (6P4C or 6P6C) / 4-pin screw terminal |
| Mechanical | |
| Dimensions (W x L x H) | 116 mm x 122 mm x 64 mm |
| Installation | DIN-Rail |
| Environment | |
| Operating Temperature | -25°C ~ +75°C |
| Storage Temperature | -30°C ~ +80°C |
| Humidity | 10 to 90% RH, Non-condensing |

2.3. Pin Assignments




RJ11 Pin Assignment



| Pin | Description | |
|-----|-------------|--|
| 1 | GND | Ground |
| 2 | DATA- | RS-485 Interface (D-) |
| 3 | DATA+ | RS-485 Interface (D+) |
| 4 | +VS | Power Input (+10 ~ +30 V _{DC}) |

Terminal Block Assignment



| Pin | Description | |
|-----|-------------|--|
| 1 | DATA+ | RS-485 Interface (D+) |
| 2 | DATA- | RS-485 Interface (D-) |
| 3 | +VS | Power Input (+10 ~ +30 V _{DC}) |
| 4 | GND | Ground |

2.4. Wire Connections


DIO Wire Connections

| Output Type | ON State LED ON Readback as 1 | OFF State LED OFF Readback as 0 |
|------------------------|----------------------------------|------------------------------------|
| Drive Relay RL1 ~ 4 | Relay ON | Relay Off |
| | | |


| Input Type | DI Read Back as 1 | DI Read Back as 0 |
|------------|-------------------|-------------------|
| AC Input | ON | Off |
| | | |

Power and Communication Connections

Using Terminal Block




Using RJ-11 Connector



2.5. DIP Switch Configuration

Configure DIP Switch Description




| | | |
|-------|-----|------------------------|
| DIP 5 | ON | DCON Protocol |
| | OFF | Modbus RTU Protocol |
| DIP 6 | ON | Software Configuration |
| | OFF | Hardware Configuration |
| DIP 7 | ON | High Node Address |
| | OFF | Low Node Address |
| DIP 8 | ON | INIT Mode |
| | OFF | Normal Mode |

Address Setting via DIP Switch Configuration

| | | |
|-----------------------|--|--|
| <p>Module Address</p> | | 0 to F for Address 128 - 143 (Node Address - Low) |
| | | 0 to F for Address 144 - 159 (Node Address High) |

DO Test DIP Switch



DO Test 1 ~ 4 are test DIP switch that control Relay 1 ~ Relay 4 ON / OFF.

RL1 ~ RL4 are LED Indicators to Relay 1 ~ 4. When a relay is ON, the corresponding LED will be ON, too.

2.5.1. INIT Mode

When the SC-6104-W5 is powered on with Configure DIP switch 8 in the ON position, the module will be set to INIT Mode. In this mode, the position of DIP switches 5 ~ 7 and the Address settings switch will be ignored and the SC-6104-W5 module will use the fixed configuration parameters listed below.

| | |
|---------------------|----------|
| Protocol: | DCON |
| Address: | 00 |
| Baud Rate: | 9600 bps |
| Data Format: | N, 8, 1 |

In this mode, the relevant commands can be used to change the configuration, and the new settings will be saved to the EEPROM.

2.5.2. Hardware Configuration Mode

When the SC-6104-W5 is powered on with both the Configure DIP switches 6 and 8 in the OFF position, the module will be set to Hardware Configuration Mode. In this mode, the following configuration parameters are used.

| | |
|---------------------|--|
| Protocol: | Dependent on the position of DIP switch 5 |
| Address: | Refer to the "Address Settings via Hardware Configuration" table above |
| Baud Rate: | Fixed at 9600 bps |
| Data Format: | Fixed to N,8,1 |

In this mode, any software command related to configuration will be ignored when using the Modbus RTU protocol, or will return an error when using the DCON protocol.

2.5.3. Software Configuration Mode

When the SC-6104-W5 is powered on with DIP switch 8 in the OFF position and DIP switch 6 in the ON position, the module will be set to Software Configuration Mode. In this mode, the configuration parameters to be used will be retrieved from the EEPROM. The default configuration parameters stored in the EEPROM is:

| | |
|---------------------|------------|
| Protocol: | Modbus RTU |
| Address: | 01 (0x01) |
| Baud Rate: | 9600 bps |
| Data Format: | N,8,1 |

In this mode, the relevant commands can be used to change the configuration parameters, and the new settings will be saved to the EEPROM.

2.6. Software Configuration Tables

Baud Rate Settings (CC)

| | | | | | | | |
|----------------------------|----------|----------|----------|-----------|----------|----------|----------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Data Bit, Parity, Stop Bit | | Reserved | | Data Rate | | | |

Data Rate (Bit 0 ~ Bit 3)

| | | | | | | | | |
|-------------|------|------|------|------|-------|-------|-------|--------|
| Code | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A |
| Baud | 1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200 |

Data Bit, Parity and Stop Bit (Bit 6 ~ Bit 7)

| | | | | |
|---------------|---------|---------|---------|---------|
| Code | 0 | 1 | 2 | 3 |
| Format | 8, n, 1 | 8, n, 2 | 8, e, 1 | 8, o, 1 |

Type Code Settings (TT)

For the SC-6104-W5, the Type Code is fixed to 40 and cannot be changed.

Data Format Settings (FF)

| | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Reserved | CS | Reserved | | | | | |

| Key | Description |
|-----------|---|
| CS | Checksum Setting 0: Disabled 1: Enabled |

Note: All Reserved bits should be zero.

3. DCON Protocol

All communication with the SC-6104-W5 consists of commands generated by the Host and responses transmitted by the SC-6104-W5 module. Each module has a unique ID number that is used for addressing purposes and is stored in non-volatile memory. The module ID number is set to 01 by default and can be changed by sending a user command. All commands to the modules contain the ID number as the address, meaning that only the addressed module will respond.

Command Format:

| | | | | |
|---------------------|----------------|---------|----------|----|
| Delimiter Character | Module Address | Command | Checksum | CR |
|---------------------|----------------|---------|----------|----|

Response Format:

| | | | | |
|---------------------|----------------|------|----------|----|
| Delimiter Character | Module Address | Data | Checksum | CR |
|---------------------|----------------|------|----------|----|

CR = End of command character, carriage return (0x0D), used to end a frame.

Note:

1. All characters should be in upper case.
2. There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

An Overview of the DCON Command Set

| General Command Set | | | |
|---------------------|-----------|--|---------|
| Command | Response | Description | Section |
| %aannttccff | !aa | Set configuration of the module | 3.1 |
| \$aa2 | !aattccff | Read configuration of the module | 3.2 |
| \$aa5 | !aa | Read reset status of the module | 3.3 |
| \$aa6 | !(data) | Read all digital input/output data | 3.4 |
| \$aaF | !aa(data) | Read firmware version of the module | 3.5 |
| \$aaLC0n | !aa | Coordinate the operation status between the digital input and the digital output | 3.6 |
| \$aaLC1 | !aan | Read whether or not the operation status between the digital input and the digital output is coordinated | 3.7 |
| \$aaLC2nnnn | !aa | Set the active delay time for the digital output | 3.8 |
| \$aaLC3 | !aannnn | Read the active delay time for the digital output | 3.9 |
| \$aaM | !aa(data) | Read module name | 3.10 |
| \$aaP | !aasc | Read communication protocol information | 3.11 |
| \$aaPc | !aa | Set communication protocol | 3.12 |
| #aa | >(data) | Read all analog input data | 3.13 |
| @aa | >(data) | Read all digital input/output data | 3.14 |
| @aah | > | Set all digital output channels | 3.15 |
| @aaDI | !aasooii | Read digital I/O and alarm status | 3.16 |
| @aaDOhh | !aa | Set digital output states | 3.17 |
| @AAA2CjT00 | !aa | Set Temperature Offset | 3.18 |
| @AAA3Cj | !aaoo | Get Temperature Offset | 3.19 |
| ~** | None | Host OK notification | 3.20 |

| | | | |
|----------|-----------|--|------|
| ~aa0 | !aass | Read host watchdog status | 3.21 |
| ~aa1 | !aa | Clear host watchdog timeout state | 3.22 |
| ~aa2 | !aaehh | Read host watchdog settings | 3.23 |
| ~aa3ehh | !aa | Set host watchdog settings | 3.24 |
| ~aa4 | !aappss | Read power-on and safe digital output values | 3.25 |
| ~aa4P | !aa(data) | Read the power-on digital output value | 3.26 |
| ~aa4S | !aa(data) | Read the safe digital output value | 3.27 |
| ~aa5ppss | !aa | Set power-on and safe digital output values | 3.28 |
| ~aa5P | !aa | Set the current digital output value as the power-on value | 3.29 |
| ~aa5S | !aa | Set the current digital output value as the safe value | 3.30 |
| ~aaD | !aat | Read temperature scale | 3.31 |
| ~aaDt | !aa | Set temperature scale | 3.32 |
| ~aaRS | !aard | Read rotary and dip switch | 3.33 |
| ~aaRD | !aa hh | Read response delay time | 3.34 |
| ~aaRDhh | !aa | Set response delay time | 3.35 |

3.1. %aannttccff

Description:

This command is used to set the configuration of a specified module.

Syntax:

%aannttccff[CHKSUM](CR)

- %** Delimiter character.
- aa** The address of the module to be set in hex format (00 to FF).
- nn** The new address of the module in hex format (00 to FF).
- tt** The Type code, which should be set to 40 for DIO modules.
- cc** The new Baud Rate, see **section 2.6** for details. The module must boot up at INIT mode (**section 2.5**) in order to change Baud Rates.
- ff** The command used to set the counter update direction and the checksum (**section 2.6**). The module must boot up at INIT mode (**section 2.5**) in order to change the checksum settings.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid. If an attempt is made to change the **Baud Rate** or **Checksum** settings without first connecting the INIT* pin to the ground pin or without switching the rear slide switch to the INIT position, the module will return a response indicating that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|---|-----------|-----|
| Command: | %0102400600 | Response: | !02 |
| | Changes the address of module 01 to 02. The module returns a response indicating that the command was valid and includes the new address of the module. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | %0101400A00 | Response: | ?01 |
| | Changes the Baud Rate of module 01 to 115200bps. The module returns a response indicating that the command was invalid, because it is not in INIT mode. | | |

| | | | |
|----------|--|-----------|-----|
| Command: | %010140CA00 | Response: | !01 |
| | Changes the Baud Rate of module 01 to 115200bps with 8 o 1 format and the module is in INIT mode. The module returns a response indicating that the command was valid. | | |

Related Command:

Section 3.2 \$aa2

Related Topics:

Section 2.5 DIP Switch Configuration

Section 2.6 Software Configuration Tables

Notes:

Changes to the address settings take effect immediately after a valid command is received. Changes to the baud rate and checksum settings take effect on the next power-on reset.

3.2. \$aa2

Description:

This command is used to read the configuration of a specified module.

Syntax:

\$aa2[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 2** The command to read the configuration of the module.

Response:

Valid Command: **!aattccff[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- tt** The type code, it should be 40 for the module.
- cc** The baud rate for the module. See section 2.6 for details.
- ff** The checksum of the module. See section 2.6 for details.

Examples:

| | | | |
|----------|--|-----------|-----------|
| Command: | \$012 | Response: | !01400600 |
| | Read the configuration of module 01 and returns a response indicating that the command was valid, and showing that the Type code is set to 40, the Baud Rate is 9600 bps, the Checksum is Disabled and the counter update direction is Falling Edge. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | \$032 | Response: | ?03 |
| | Attempts to read the configuration of module 03, but returns a response indicating that the command was invalid because module 03 does not exist. | | |

Related Command:

Section 3.1 %aannttcff

Related Topics:

Section 2.5 DIP Switch Configuration

Section 2.6 Software Configuration Tables.

3.3. \$aa5

Description:

This command is used to read the reset status for a specified module.

Syntax:

\$aa5[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 5** The command to read the reset status of the module.

Response:

Valid Command: **!aaS[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- 5** The reset status of the module:
 - 0: This is **NOT** the first time the command has been sent since the module was powered on, which denotes that there has been no module reset since the last \$AA5 command was sent.
 - 1: This is the first time the \$AA5 command has been sent since the module was powered on.

Examples:

| | | | |
|----------|--|-----------|------|
| Command: | \$015 | Response: | !011 |
| | Read the reset status for module 01 and returns a response indicating that the command was valid, and that it is the first time the \$AA5 command has been sent since the module was powered on. | | |

| | | | |
|----------|--|-----------|-------|
| Command: | \$015 | Response: | \$010 |
| | Read the reset status for module 01 and returns a response indicating that the command was valid, and that there has been no module reset since the last \$AA5 command was sent. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | \$035 | Response: | ?03 |
| | Attempts to read the reset status for module 03, but returns a response indicating that the command was invalid because module 03 does not exist. | | |

Related Command:

None

Related Topics:

None

3.4. \$aa6

Description:

This command is used to read the status of both the digital input and digital output channels of a specified module.

Syntax:

\$aa6[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 6** The command to read the status of the Digital I/O channels.

Response:

Valid Command: **!(data)[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- (data)** The status of the digital output and digital input channels represented by a four-digit hexadecimal value followed by 00. The first two digits represent the status of the digital output channels and the second two represent the status of the digital input channels.

(data) Format:

(Byte 1)(Byte 2)00

- Byte 1** Digital output data. Range is 00 ~ 0F.
- Byte 2** Digital input data. Range is 00 ~ 01.
- 00** Fix response end of the command.

Examples:

| | | | |
|----------|--|-----------|---------|
| Command: | \$026 | Response: | !0F0100 |
| | Read the status of the digital output and digital input channels for module 02 and returns a response indicating that the command was valid and that the current digital output value is 0F and the current digital input value is 01 denoting that both the digital output and digital input channels are ON. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | \$036 | Response: | ?03 |
| | Attempts to read the status of the digital output and digital input channels for module 03 and returns a response indicating that the command was invalid because module 03 does not exist. | | |

Related Command:

Section 3.14 @aa , Section 3.15 @aah
Section 3.16 @aaDI , Section 3.17 @aaDOhh

Related Topics:

None

3.5. \$aaF

Description:

This command is used to read the firmware version of a specified module.

Syntax:

\$aaF[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- F** The command to read the firmware version.

Response:

Valid Command: **!aa(data)[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- (data)** A string indicating the firmware version of the module.

Examples:

| | | | |
|----------|---|-----------|----------|
| Command: | \$01F | Response: | !0101.00 |
| | Read the firmware version of module 01, and returns a response indicating that the command was valid, and that the firmware version is 01.00. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | \$03F | Response: | ?03 |
| | Attempts to read the firmware version of module 03 and returns a response indicating that the command was invalid because module 03 does not exist. | | |

Related Command:

None

Related Topics:

None

3.6. \$aaLC0n

Description:

This command is used to coordinate the operation status between the digital input and the digital output for a specified module.

Syntax:

\$aaLC0n[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- LC0** The command to coordinate the operation status between the digital input and the digital output.
- n** The DI DO coordinated function number.
0: The ON/OFF sequence of the digital output will **NOT** be coordinated when the status of the digital input is changed.
Others: The ON/OFF sequence of the digital output will be coordinated with **n** function when the status of the digital input is changed.

The command to set the operating status:

| n | The ON/OFF Sequence of The Digital Output | | | | |
|----------|---|----------|----------|----------|----------|
| 0 | Coordinated Disable | | | | |
| 1 | DI coordinated with RL1 ~ 4, the 4 operating status are: <table border="1" style="width: 100%; text-align: center;"> <tr> <td>NO 0 0 0</td> <td>NO 1 0 0</td> <td>NO 1 1 0</td> <td>NO 1 1 1</td> </tr> </table> | NO 0 0 0 | NO 1 0 0 | NO 1 1 0 | NO 1 1 1 |
| NO 0 0 0 | NO 1 0 0 | NO 1 1 0 | NO 1 1 1 | | |
| 2 | DI coordinated with RL1 ~ 4, the 4 operating status are: <table border="1" style="width: 100%; text-align: center;"> <tr> <td>NO 0 0 0</td> <td>NC 1 0 0</td> <td>NC 0 1 0</td> <td>NC 0 0 1</td> </tr> </table> | NO 0 0 0 | NC 1 0 0 | NC 0 1 0 | NC 0 0 1 |
| NO 0 0 0 | NC 1 0 0 | NC 0 1 0 | NC 0 0 1 | | |
| 3 | DI coordinated with RL1 ~ 4, the 3 operating status are: <table border="1" style="width: 100%; text-align: center;"> <tr> <td>NO 1 0 0</td> <td>NO 1 1 0</td> <td>NO 1 1 1</td> </tr> </table> | NO 1 0 0 | NO 1 1 0 | NO 1 1 1 | |
| NO 1 0 0 | NO 1 1 0 | NO 1 1 1 | | | |
| 4 | DI coordinated with RL1 ~ 4, the 3 operating status are: <table border="1" style="width: 100%; text-align: center;"> <tr> <td>NO 1 0 0</td> <td>NO 0 1 0</td> <td>NO 0 0 1</td> </tr> </table> | NO 1 0 0 | NO 0 1 0 | NO 0 0 1 | |
| NO 1 0 0 | NO 0 1 0 | NO 0 0 1 | | | |
| 5 | DI coordinated with RL2 ~ 4, the 3 operating status are: <table border="1" style="width: 100%; text-align: center;"> <tr> <td>X 1 0 0</td> <td>X 1 1 0</td> <td>X 1 1 1</td> </tr> </table> | X 1 0 0 | X 1 1 0 | X 1 1 1 | |
| X 1 0 0 | X 1 1 0 | X 1 1 1 | | | |
| 6 | DI coordinated with RL1 ~ 4, the 3 operating status are: <table border="1" style="width: 100%; text-align: center;"> <tr> <td>X 1 0 0</td> <td>X 0 1 0</td> <td>X 0 0 1</td> </tr> </table> | X 1 0 0 | X 0 1 0 | X 0 0 1 | |
| X 1 0 0 | X 0 1 0 | X 0 0 1 | | | |
| 7 | DI coordinated only with RL1. When the DI gets high, RL1 is switch to NO. When the DI gets low, RL1 is switch to NC. | | | | |

The description of symbols of above list is below.

- NO : RL1 Normal Open
- NC : RL1 Normal Close
- 0 : DO Off
- 1 : DO On
- X : don't care

Response:

Valid Command: **>aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- >** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | \$01LC01 | Response: | !01 |
| | Coordinates the function 1 operation between the digital input and the digital output of module 01, and the module returns a response indicating that the command was valid. | | |

Related Command:

Section 3.7 \$aaLC1

Related Topics:

None

3.7. \$aaLC1

Description:

This command is used to read whether the operation between the digital input and the digital output for a specified module is coordinated.

Syntax:

\$aaLC1[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- LC1** The command to read whether the operation between the digital input and the digital output is coordinated

Response:

Valid Command: **!aan[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- n** The operation status:
 - 0: The ON/OFF sequence of the digital output is NOT coordinated when the status of the digital input is changed
 - 1: The ON/OFF sequence of the digital output is coordinated when the status of the digital input is changed

Examples:

| | | | |
|----------|---|-----------|------|
| Command: | \$01LC1 | Response: | !011 |
| | Read whether the operation between the digital input and the digital output is coordinated and the module returns a response indicating that the command was valid with a value of 1 meaning that the sequence of the digital output will be coordinated with function 1 when the status of the digital input is changed. | | |

Related Command:

Section 3.6 \$aaLC0n

Related Topics:

None

3.8. \$aaLC2nnnn

Description:

This command is used to set the active delay time for the digital output of a specified module.

Syntax:

\$aaLC2nnnn[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- LC2** The command to set the active delay time for the digital output.
- nnnn** A four-digit hexadecimal value representing the active delay time in milliseconds. The maximum delay time is 0x0BB8 (3000 milliseconds).

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | \$01LC203E8 | Response: | !01 |
| | Set the active delay time for the digital output of module 01 to 0x03E8 (1000 milliseconds) and the module returns a response indicating that the command was valid. The digital output will be active 1000 milliseconds after the module is powered on. | | |

| | | | |
|----------|--|-----------|-----|
| Command: | \$01LC20BB9 | Response: | ?01 |
| | Attempts to set the active delay time for the digital output of module 01 to 0x0BB9 (3001 milliseconds), but the module returns a response indicating that the command was invalid because the value for the active delay time was not within the valid range. | | |

Related Command:

Section 3.9 \$aaLC3

Related Topics:

None

3.9. \$aaLC3

Description:

This command is used to read the active delay time for the digital output of a specified module.

Syntax:

\$aaLC3[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- LC3** The command to read the active delay time for the digital output.

Response:

Valid Command: **!aannnn[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- nnnn** A four-digit hexadecimal value representing the active delay time in milliseconds

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | \$01LC20BB8 | Response: | !01 |
| | Set the active delay time for the digital output of module 01 to 0x0BB8 (3000 milliseconds) and the module returns a response indicating that the command was valid. The digital output will be active 3000 milliseconds after the module is powered on. | | |

| | | | |
|----------|--|-----------|---------|
| Command: | \$01LC3 | Response: | !010BBB |
| | Read the active delay time for the digital output of module 01 and returns a response indicating that the command was valid, with a value of 0BB8 meaning that the active delay time is 3000 milliseconds. | | |

Related Command:

Section 3.8 \$aaLC2nnn

Related Topics:

None

3.10. \$aaM

Description:

This command is used to read the name of a specified module.

Syntax:

\$aaM[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- M** The command to read the name of the module.

Response:

Valid Command: **!aa(data)[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- (data)** A string indicating the name of the module.

Examples:

| | | | |
|----------|---|-----------|-----------|
| Command: | \$02M | Response: | !02SC6104 |
| | Read the name of module 02 and returns a response indicating that the command was valid, and that the name of the module is SC-6104-W5. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | \$03M | Response: | ?03 |
| | Attempts to read the name of module 03 and returns a response indicating that the command was invalid because module 03 does not exist. | | |

Related Command:

None

Related Topics:

None

3.11. \$aaP

Description:

This command is used to read the communication protocol information for a specified module.

Syntax:

\$aaP[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- P** The command to read the communication protocol information.

Response:

Valid Command: **!aasc[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- s** The protocols supported by the module:
 - 0: Only the DCON protocol is supported.
 - 1: Both the DCON and Modbus RTU protocols are supported.
- c** The current protocol that is saved in the EEPROM that will be used at the next power-on reset:
 - 0: The protocol saved in the EEPROM is DCON.
 - 1: The protocol saved in the EEPROM is Modbus RTU.

Examples:

| | | | |
|----------|---|-----------|-------|
| Command: | \$01P | Response: | !0110 |
| | Read the communication protocol information for module 01 returns a response indicating that the command was valid, with a value of 10, which denotes that the module supports both the DCON and Modbus RTU protocols and that the protocol that will be used at the next power-on reset is DCON. | | |

| | | | |
|----------|--|-----------|-----|
| Command: | \$03P | Response: | ?03 |
| | Attempts to read the communication protocol information for module 03 and returns a response indicating that the command was invalid because module 03 does not exist. | | |

Related Command:

Section 3.12 \$aaPn

Related Topics:

None

3.12. \$aaPc

Description:

This command is used to set the communication protocol for a specified module.

Syntax:

\$aaPc[CHKSUM](CR)

- \$** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- P** The command to set the communication protocol.
- c** The protocol to be used:
 - 0: DCON Protocol
 - 1: Modbus RTU Protocol

Note:

Before using this command, the module must be boot up at INIT mode (**section 2.5**) if in DCON protocol mode. The new protocol information will be saved in the EEPROM and will become effective after the next power-on reset.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|---|-----------|-----|
| Command: | \$01P1 | Response: | ?01 |
| | Attempts to set the communication protocol to be used for module 01 to Modbus RTU, but returns a response indicating that the command was invalid because the module is not in INIT mode. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | \$01P1 | Response: | !01 |
| | Set the communication protocol to be used for module 01 to Modbus RTU and returns a response indicating that the command was valid. | | |

Related Command:

Section 3.11 \$aaP

Related Topics:

Section 2.5 DIP Switch Configuration

3.13. #aa

Description:

This command is used to read analog input data of the module.

Syntax:

#aa[CHKSUM](CR)

Delimiter character.

aa The address of the module to be read in hex format (00 to FF).

Response:

Valid Command: **>(data)[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

! Delimiter character to indicate that the command was valid.

? Delimiter character to indicate that the command was invalid.

aa The address of the responding module in hex format (00 to FF).

(data) Analog input value in engineer unit format.

Examples:

| | | | |
|----------|---|-----------|------|
| Command: | ~01D | Response: | !010 |
| | Read the temperature scale for module 01 returns a response indicating that the command was valid, with a value of 0, which denotes that the temperature scale is Celsius (°C). | | |

| | | | |
|----------|---|-----------|----------|
| Command: | #01 | Response: | >+026.40 |
| | Read the temperature analog value for module 01 returns a response indicating that the command was valid, with a value of +026.40, which denotes that the temperature sensor indicated now is 26.4°C. | | |

Related Command:

Section 3.18 @aaA2CjToo Section 3.19 @aaA3Cj
Section 3.31 ~aaD Section 3.32 ~aaDt

Related Topics:

None

3.14. @aa

Description:

This command is used to read the status of both the digital output and digital input channels of a specified module.

Syntax:

@aa[CHKSUM](CR)

- @** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).

Response:

Valid Command: **>(data)[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- (data)** The status of the digital output and digital input channels represented by a four-digit hexadecimal value. The first two digits represent the status of the digital output channels and the second two represent the status of the digital input channels.

(data) Format:

(Byte 1)(Byte 2)

- Byte 1** Digital output data. Range is 00 ~ 0F.
- Byte 2** Digital input data. Range is 00 ~ 01.

3.15. @aah

Description:

This command is used to set the value for all digital output channels of a specified module.

Syntax:

@aah[CHKSUM](CR)

- @ Delimiter character.
- aa The address of the module to be read in hex format (00 to FF).
- h A single-digit hexadecimal value representing the data to be written to the digital output channels, where bit 0 ~ 3 of the value corresponds to channel RL1 ~ RL4. When the bit is 0, it denotes that the digital output channel is set to OFF, and 1 denotes that the digital output channel is set to ON.

Response:

Valid Command: >[CHKSUM](CR)

Invalid Command: ?aa[CHKSUM](CR)

Ignored Command: ![CHKSUM](CR)

- > Delimiter character to indicate that the command was valid.
- ? Delimiter character to indicate that the command was invalid.
- ! Delimiter character to indicate that the command was ignored.
The module is in host watchdog timeout mode, and the output is set to safe value.

Examples:

| | | | |
|----------|---|-----------|---|
| Command: | @023 | Response: | > |
| | Set channels RL1 and RL2 of module 02 to ON, and the module returns a response indicating that the command was valid. | | |

Related Command:

Section 3.4 \$aa6 , Section 3.14 @aa

Section 3.16 @aaDI , Section 3.17 @aaDOhh

Related Topics:

None

3.16. @aaDI

Description:

This command is used to read the status of both the digital output and digital input channels and alarm status of a specified module.

Syntax:

@aaDI[CHKSUM](CR)

- @** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- DI** The command to read the digital I/O and alarm status.

Response:

Valid Command: **!aasooii[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- s** Alarm status. Now the parameter is reserved and got always 0.
- oo** Digital output data. Range is 00 ~ 0F.
- ii** Digital input data. Range is 00 ~ 01.

Examples:

| | | | |
|----------|--|-----------|----------|
| Command: | @01DI | Response: | !0100F01 |
| | Read the status of the digital output and digital input channels for module 01 and returns a response indicating that the command was valid and that the current digital output value is 0F and the current digital input value is 01 denoting that both the digital output and digital input channels are ON. | | |

Related Command:

- Section 3.4 \$aa6 , Section 3.14 @aa
- Section 3.15 @aah , Section 3.17 @aaDOhh

Related Topics:

None

3.17. @aaDOhh

Description:

This command is used to set the value for all digital output channels of a specified module.

Syntax:

@aaDOhh[CHKSUM](CR)

- @** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- DO** The command to set the digital output of the module.
- hh** A byte hexadecimal value representing the data to be written to the digital output channels, where bit 0 ~ 3 of the value corresponds to channel RL1 ~ RL4 and others bit must be 0. When the bit is 0, it denotes that the digital output channel is set to OFF, and 1 denotes that the digital output channel is set to ON.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|---|-----------|-----|
| Command: | @02DO0F | Response: | !aa |
| | Set channels RL1 ~ RL4 of module 02 to ON, and the module returns a response indicating that the command was valid. | | |

Related Command:

Section 3.4 \$aa6 , Section 3.14 @aa
Section 3.15 @aah , Section 3.16 @aaDI

Related Topics:

None

3.18. @aaA2CjToo

Description:

This command is used to set the temperature offset value of a specified module.

Syntax:

@aaA2CjToo[CHKSUM](CR)

- @** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- A2C** The command to select temperature channel to set.
- j** Temperature input channel. For SC-6104-W5 must be 0.
- T** The command to set temperature offset value.
- oo** Temperature offset value in Hex format. 00 ~ 7F is plus value (+0 ~ +127) and FF ~ 80 is minus value (-1 ~ -128). The offset temperature unit is 0.1.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|---|-----------|------|
| Command: | ~01D | Response: | !010 |
| | Read the temperature scale for module 01 returns a response indicating that the command was valid, with a value of 0, which denotes that the temperature scale is Celsius (°C). | | |

| | | | |
|----------|---|-----------|----------|
| Command: | #01 | Response: | >+026.40 |
| | Read the temperature analog value for module 01 returns a response indicating that the command was valid, with a value of +026.40, which denotes that the temperature sensor indicated now is 26.4°C. | | |

| | | | |
|----------|--|-----------|-----|
| Command: | @01A2C0T06 | Response: | !01 |
| | Set the temperature offset to 06 and returns a response indicating that the command was valid. | | |

| | | | |
|----------|--|-----------|----------|
| Command: | #01 | Response: | >+027.00 |
| | Read the temperature analog value for module 01 returns a response indicating that the command was valid, with a value of +027.00, which denotes that the temperature sensor indicated now is 27°C (26.4 + 0.6). | | |

Related Command:

Section 3.13 #aa Section 3.19 @aaA3Cj
Section 3.31 ~aaD Section 3.32 ~aaDt

Related Topics:

None

3.19. @aaA3Cj

Description:

This command is used to read the temperature offset value of a specified module.

Syntax:

@aaA3Cj [CHKSUM](CR)

- @** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- A3C** The command to select temperature channel to read.
- j** Temperature input channel. For SC-6104-W5 must be 0.

Response:

Valid Command: **!aaoo[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- oo** Temperature offset value in Hex format. 00 ~ 7F is plus value (+0 ~ +127) and FF ~ 80 is minus value (-1 ~ -128). The offset temperature unit is 0.1.

Examples:

| | | | |
|----------|--|-----------|-------|
| Command: | @01A3C0 | Response: | !0106 |
| | Read the temperature offset value for module 01 returns a response indication that the command was valid, with a value of 06, which demotes that the temperature offset is +0.6. | | |

Related Command:

- Section 3.13 #aa
- Section 3.18 @aaA2CjToo
- Section 3.31 ~aaD
- Section 3.32 ~aaDt

Related Topics:

None

3.20. ~**

Description:

Host sends this command to all modules for broadcasting the information "Host OK". If the module waits the command timeout when enable WDT function. The module will in host watchdog timeout mode, and the output is set to safe value.

Syntax:

~** [CHKSUM](CR)

- ~ Delimiter character.
- ** Command for all modules.

Response:

None

Examples:

| | | | |
|----------|--------------------------------|-----------|-------------|
| Command: | ~** | Response: | No response |
| | Send "Host OK" to all modules. | | |

Related Command:

| | | | |
|--------------|----------|--------------|---------|
| Section 3.21 | ~aa0 | Section 3.22 | ~aa1 |
| Section 3.23 | ~aa2 | Section 3.24 | ~aa3ehh |
| Section 3.25 | ~aa4 | Section 3.27 | ~aa4S |
| Section 3.28 | ~aa5ppss | Section 3.30 | ~aa5S |

Related Topics:

None

3.21. ~aa0

Description:

Read host watchdog status of the module.

Syntax:

~aa0 [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 0** The command to read host watchdog status.

Response:

Valid Command: **!aass[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- ss** Host watchdog status. The status will store into flash and only may reset by the command ~aa1.

| | | | | | | | |
|----|----------|---|---|----|----------|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| *1 | Reserved | | | *2 | Reserved | | |

***1: Host watchdog status, 0=disable, 1=enable**

***2: Host watchdog timeout flag, 0=clear, 1=set**

Examples:

| | | | |
|----------|--|-----------|-------|
| Command: | ~010 | Response: | !0104 |
| | Read module 01 host watchdog status returns 04, host watchdog timeout flag is set. | | |

Related Command:

| | | | |
|--------------|----------|--------------|---------|
| Section 3.20 | ~** | Section 3.22 | ~aa1 |
| Section 3.23 | ~aa2 | Section 3.24 | ~aa3ehh |
| Section 3.25 | ~aa4 | Section 3.27 | ~aa4S |
| Section 3.28 | ~aa5ppss | Section 3.30 | ~aa5S |

Related Topics:

None

3.22. ~aa1

Description:

Reset host watchdog status of the module.

Syntax:

~aa1 [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 1** The command to reset host watchdog status.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|--|-----------|-------|
| Command: | ~010 | Response: | !0104 |
| | Read module 01 host watchdog status returns 04, host watchdog timeout flag is set. | | |

| | | | |
|----------|---|-----------|-----|
| Command: | ~011 | Response: | !01 |
| | Reset module 01 host watchdog status returns success. | | |

| | | | |
|----------|--|-----------|-------|
| Command: | ~010 | Response: | !0100 |
| | Read module 01 host watchdog status returns 00, host watchdog timeout flag is clear. | | |

Related Command:

| | | | |
|--------------|----------|--------------|---------|
| Section 3.20 | ~** | Section 3.21 | ~aa0 |
| Section 3.23 | ~aa2 | Section 3.24 | ~aa3ehh |
| Section 3.25 | ~aa4 | Section 3.27 | ~aa4S |
| Section 3.28 | ~aa5ppss | Section 3.30 | ~aa5S |

Related Topics:

None

3.23. ~aa2

Description:

Read host watchdog activation and timeout interval.

Syntax:

~aa2 [CHKSUM](CR)

- ~ Delimiter character.
- aa The address of the module to be read in hex format (00 to FF).
- 2 The command to read host watchdog activation and timeout interval.

Response:

Valid Command: **!aaehh[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- ! Delimiter character to indicate that the command was valid.
- ? Delimiter character to indicate that the command was invalid.
- aa The address of the responding module in hex format (00 to FF).
- e Host watchdog activation, 0=disable, 1=enable.
- hh Timeout interval in Hex format, each count for 0.1 second, ex: 01 = 0.1 second and FF = 25.5 seconds.

Examples:

| | | | |
|----------|--|-----------|--------|
| Command: | ~012 | Response: | !011FF |
| | Read module 01 host watchdog activation and timeout interval returns 1FF, host watchdog is enabled now and timeout interval is 25.5 seconds. | | |

Related Command:

- | | | | |
|--------------|----------|--------------|---------|
| Section 3.20 | ~** | Section 3.21 | ~aa0 |
| Section 3.22 | ~aa1 | Section 3.24 | ~aa3ehh |
| Section 3.25 | ~aa4 | Section 3.27 | ~aa4S |
| Section 3.28 | ~aa5ppss | Section 3.30 | ~aa5S |

Related Topics:

None

3.24. ~aa3ehh

Description:

Set host watchdog activation and timeout interval.

Syntax:

~aa3ehh [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 3** The command to set host watchdog activation and timeout interval.
- e** Host watchdog activation, 0=disable, 1=enable.
- hh** Timeout interval in Hex format, each count for 0.1 second, ex: 01 = 0.1 second and FF = 25.5 seconds.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | ~013164 | Response: | !01 |
| | Set module 01 enable host watchdog and timeout interval is 64 (10.0 seconds), returns success. | | |

Related Command:

| | | | |
|--------------|----------|--------------|-------|
| Section 3.20 | ~** | Section 3.21 | ~aa0 |
| Section 3.22 | ~aa1 | Section 3.23 | ~aa2 |
| Section 3.25 | ~aa4 | Section 3.27 | ~aa4S |
| Section 3.28 | ~aa5ppss | Section 3.30 | ~aa5S |

Related Topics:

None

3.25. ~aa4

Description:

Read power-on value and safe value of digital output for a specified module.

Syntax:

~aa4 [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 4** The command to read power-on value and safe value of digital output.

Response:

Valid Command: **!aappss[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- pp** The digital output power-on value.
- ss** The digital output safe value.

Examples:

| | | | |
|----------|--|-----------|---------|
| Command: | ~014 | Response: | !010F03 |
| | Read module 01 power-on and safe value returns power-on value is 0F, safe value is 03. | | |

Related Command:

| | | | |
|--------------|---------|--------------|----------|
| Section 3.20 | ~** | Section 3.21 | ~aa0 |
| Section 3.22 | ~aa1 | Section 3.23 | ~aa2 |
| Section 3.24 | ~aa3ehh | Section 3.26 | ~aa4P |
| Section 3.27 | ~aa4S | Section 3.28 | ~aa5ppss |
| Section 3.29 | ~aa5P | Section 3.30 | ~aa5S |

Related Topics:

None

3.26. ~aa4P

Description:

Read power-on value of digital output for a specified module.

Syntax:

~aa4P [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 4P** The command to read power-on value of digital output.

Response:

Valid Command: **!aa(data)[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- (data)** The digital output power-on value.

Examples:

| | | | |
|----------|---|-----------|---------|
| Command: | ~014P | Response: | !010F00 |
| | Read module 01 power-on value returns 0F. | | |

Related Command:

- Section 3.25 ~aa4
- Section 3.28 ~aa5ppss
- Section 3.29 ~aa5P

Related Topics:

None

3.27. ~aa4S

Description:

This command is used to read the digital output safe value for a specified module.

Syntax:

~aa4S [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 4S** The command to read safe value of digital output.

Response:

Valid Command: **!aa(data)[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- (data)** The digital output safe value.

Examples:

| | | | |
|----------|---------------------------------------|-----------|---------|
| Command: | ~014S | Response: | !010300 |
| | Read module 01 safe value returns 03. | | |

Related Command:

| | | | |
|--------------|----------|--------------|-------|
| Section 3.20 | ~** | Section 3.21 | ~aa0 |
| Section 3.22 | ~aa1 | Section 3.23 | ~aa2 |
| Section 3.24 | ~aa3ehh | Section 3.25 | ~aa4 |
| Section 3.28 | ~aa5ppss | Section 3.30 | ~aa5S |

Related Topics:

None

3.28. ~aa5ppss

Description:

Set power-on value and safe value of digital output to a specified module.

Syntax:

~aa5ppss [CHKSUM](CR)

- ~ Delimiter character.
- aa The address of the module to be read in hex format (00 to FF).
- 5 The command to set power-on value and safe value of digital output.
- pp The digital output power-on value.
- ss The digital output safe value.

Response:

Valid Command: !aa[CHKSUM](CR)

Invalid Command: ?aa[CHKSUM](CR)

- ! Delimiter character to indicate that the command was valid.
- ? Delimiter character to indicate that the command was invalid.
- aa The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | ~0150F03 | Response: | !01 |
| | Set module 01 power-on value to 0F and safe value to 03 and returns success. | | |

Related Command:

| | | | |
|--------------|---------|--------------|-------|
| Section 3.20 | ~** | Section 3.21 | ~aa0 |
| Section 3.22 | ~aa1 | Section 3.23 | ~aa2 |
| Section 3.24 | ~aa3ehh | Section 3.25 | ~aa4 |
| Section 3.26 | ~aa4P | Section 3.27 | ~aa4S |
| Section 3.29 | ~aa5P | Section 3.30 | ~aa5S |

Related Topics:

None

3.29. ~aa5P

Description:

Set current digital output value as the power-on value for a specified module.

Syntax:

~aa5P [CHKSUM](CR)

- ~ Delimiter character.
- aa The address of the module to be read in hex format (00 to FF).
- 5P Command for setting current digital output value as the power-on value.

Response:

Valid Command: !aa[CHKSUM](CR)

Invalid Command: ?aa[CHKSUM](CR)

- ! Delimiter character to indicate that the command was valid.
- ? Delimiter character to indicate that the command was invalid.
- aa The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|---|-----------|---|
| Command: | @01F | Response: | > |
| | Set module 01 digital output value to F, and the module returns a response indicating that the command was valid. | | |

| | | | |
|----------|--|-----------|-----|
| Command: | ~015P | Response: | !01 |
| | Set current digital output value of module 01 as the power-on value and returns success. | | |

Related Command:

- Section 3.25 ~aa4 Section 3.26 ~aa4P
- Section 3.28 ~aa5ppss

Related Topics:

None

3.30. ~aa5S

Description:

Set current digital output value as the safe value for a specified module.

Syntax:

~aa5S [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- 5S** Command for setting current digital output value as the safe value.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|---|-----------|---|
| Command: | @013 | Response: | > |
| | Set module 01 digital output value to 3, and the module returns a response indicating that the command was valid. | | |

| | | | |
|----------|--|-----------|-----|
| Command: | ~015S | Response: | !01 |
| | Set current digital output value of module 01 as the safe value and returns success. | | |

Related Command:

| | | | |
|--------------|---------|--------------|-----------|
| Section 3.20 | ~** | Section 3.21 | ~aa0 |
| Section 3.22 | ~aa1 | Section 3.23 | ~aa2 |
| Section 3.24 | ~aa3ehh | Section 3.25 | ~aa4 |
| Section 3.27 | ~aa4S | Section 3.28 | ~ aa5ppss |

Related Topics:

None

3.31. ~aaD

Description:

Read temperature scale of the module.

Syntax:

~aaD [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- D** The command for read temperature scale.

Response:

Valid Command: **!aat[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- t** Temperature scale. C → Celsius (°C), F → Fahrenheit (°F)

Examples:

| | | | |
|----------|--|-----------|------|
| Command: | ~01D | Response: | !01C |
| | Read module 01 temperature scale returns C (°C). | | |

Related Command:

Section 3.13 #aa Section 3.32 ~aaDt

Related Topics:

None

3.32. ~aaDt

Description:

Set temperature scale to the module.

Syntax:

~aaDt [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- D** The command for read temperature scale.
- t** Temperature scale. C → Celsius (°C), F → Fahrenheit (°F)

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | ~01DF | Response: | !01 |
| | Set module 01 temperature scale to F (°F) and returns success. | | |

| | | | |
|----------|--|-----------|------|
| Command: | ~01D | Response: | !01F |
| | Read module 01 temperature scale returns F (°F). | | |

Related Command:

Section 3.13 #aa Section 3.31 ~aaD

Related Topics:

None

3.33. ~aaRS

Description:

Read current address and configure DIP switch value of the module.

Syntax:

~aaRS [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- RS** The command for read the DIP switches value.

Response:

Valid Command: **!aard[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- r** Address DIP switch value, range is from 0 ~ F.
- d** Configure DIP switch value, range is from 0 ~ F.

Examples:

| | | | |
|----------|--|-----------|-------|
| Command: | ~03RS | Response: | !0331 |
| | Read module 03 switch value returns address DIP switch value is 3 and configure DIP switch value is 1. | | |

Related Command:

None

Related Topics:

Section 2.5 DIP Switch Configuration

3.34. ~aaRD

Description:

This command is used to read the response delay time for a specified module.

Syntax:

~aaRD [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- RD** The command to read the response delay time.

Response:

Valid Command: **!aahh[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).
- hh** Response delay time, range is from 00 ~ 1E in 1 ms intervals.

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | ~03RD1E | Response: | !03 |
| | Set the response delay time for module 03 to 1E (30 ms), and returns a response indicating that the command was valid. | | |

| | | | |
|----------|--|-----------|-------|
| Command: | ~03RD | Response: | !031E |
| | Read the response delay time for module 03 and returns a response indicating that the command was valid, with a value of 1E (30 ms). | | |

Related Command:

Section 3.35 ~aaRDhh

Related Topics:

None

3.35. ~aaRDhh

Description:

This command is used to set the response delay time for a specified module.

Syntax:

~aaRDhh [CHKSUM](CR)

- ~** Delimiter character.
- aa** The address of the module to be read in hex format (00 to FF).
- RD** The command to read the response delay time.
- hh** Response delay time, range is from 00 ~ 1E in 1 ms intervals.

Response:

Valid Command: **!aa[CHKSUM](CR)**

Invalid Command: **?aa[CHKSUM](CR)**

- !** Delimiter character to indicate that the command was valid.
- ?** Delimiter character to indicate that the command was invalid.
- aa** The address of the responding module in hex format (00 to FF).

Examples:

| | | | |
|----------|--|-----------|-----|
| Command: | ~03RD1E | Response: | !03 |
| | Set the response delay time for module 03 to 1E (30 ms), and returns a response indicating that the command was valid. | | |

| | | | |
|----------|--|-----------|-------|
| Command: | ~03RD | Response: | !031E |
| | Read the response delay time for module 03 and returns a response indicating that the command was valid, with a value of 1E (30 ms). | | |

Related Command:

Section 3.34 ~aaRD

Related Topics:

None

4. Modbus RTU Protocol

The Modbus protocol was originally developed for Modicon controllers by Modicon Inc. Detailed information related to the Modbus RTU protocol can be found at <http://www.modbus.org> for more valuable information.

The SC-6104-W5 module supports the Modbus RTU protocol, with communication baud rates ranging from 1200 bps to 115200 bps. The data bits, parity and stop bits are supported 8 n 1, 8 n 2, 8 e 1 and 8 o 1. The following Modbus functions are supported.

| Function Code | Description | Section |
|---------------|--------------------------------|---------|
| 0x01 | Read the coils | |
| 0x02 | Read the discrete inputs | |
| 0x03 | Read multiple registers | |
| 0x04 | Read multiple input registers | |
| 0x05 | Write a single coil | |
| 0x06 | Write a single register | |
| 0x0F | Write multiple coils | |
| 0x10 | Write multiple registers | |
| 0x46 | Read/Write the module settings | |

If the function specified in the message is not supported, then the module responds as below. Note that the address mapping for the Modbus protocol is Base 0.

Error Response

| Byte | Description | Length (Byte) | Value |
|------|----------------|---------------|---|
| 00 | Address | 1 | 1 ~ 247 |
| 01 | Function Code | 1 | Function Code + 0x80 |
| 02 | Exception Code | 1 | 02: Register not support 03: Modbus format invalid |

Note: If a CRC mismatch occurs, the module will not respond.

4.1. Modbus Address Mapping

Coils

| Address | | Description | Attribute |
|---------|-------|--|-----------|
| 00001 | 10001 | Digital Output RL1 | R / W |
| 00002 | 10002 | Digital Output RL2 | R / W |
| 00003 | 10003 | Digital Output RL3 | R / W |
| 00004 | 10004 | Digital Output RL4 | R / W |
| | 10033 | Digital Input Channel | R |
| 00129 | 10129 | Digital Output RL1 Safe Value | R / W |
| 00130 | 10130 | Digital Output RL2 Safe Value | R / W |
| 00131 | 10131 | Digital Output RL3 Safe Value | R / W |
| 00132 | 10132 | Digital Output RL4 Safe Value | R / W |
| 00161 | 10161 | Digital Output RL1 Power-on Value | R / W |
| 00162 | 10162 | Digital Output RL2 Power-on Value | R / W |
| 00163 | 10163 | Digital Output RL3 Power-on Value | R / W |
| 00164 | 10164 | Digital Output RL4 Power-on Value | R / W |
| 00257 | 10257 | Communication Protocol 0: DCON 1: Modbus RTU | R / W |
| 00260 | 10260 | Modbus host watchdog mode 0: do not allow DO command when watchdog timeout occur 1: can use DO command to clear host watchdog timeout status | R / W |
| 00261 | 10261 | 1: enable, 0: disable host watchdog | R / W |
| 00267 | 10267 | Temperature Scale 0: Celsius (°C) 1: Fahrenheit (°F) | R / W |
| 00268 | 10268 | DCON Protocol Checksum 0: Enable 1: Disable | R / W |
| 00270 | 10270 | Host watch dog timeout status, write 1 to clear host watch dog timeout status | R / W |
| 00273 | 10273 | Read the Reset Status 0: This is NOT the first time the module has been read since being powered on | R |

| | | | |
|-------|-------|---|-------|
| | | 1: This is the first time the module has been read since being powered on | |
| 00274 | 10274 | Coordinate the status between DI and DO 0: Enable 1: Disable | R / W |
| | 10321 | Configure DIP Switch Bit 0 | R |
| | 10322 | Configure DIP Switch Bit 1 | R |
| | 10323 | Configure DIP Switch Bit 2 | R |
| | 10324 | Configure DIP Switch Bit 3 | R |
| | 10325 | Address DIP Switch Bit 0 | R |
| | 10326 | Address DIP Switch Bit 1 | R |
| | 10327 | Address DIP Switch Bit 2 | R |
| | 10328 | Address DIP Switch Bit 3 | R |

Register

| Address | | Description | Attribute |
|---------|-------|--|-----------|
| 30001 | | Temperature Analog Input Channel | R |
| 30274 | 40274 | Coordinate Function 0 ~ 7 (refer to section 3.6) | R / W |
| 30289 | 40289 | Temperature Offset (offset unit: 0.1) | R / W |
| 30481 | | Firmware Version (Low Word) | R |
| 30482 | | Firmware Version (High Word) Read 40482 and 40483 Response: 0x00 0x01 0x00 0x01 (version 1.01) | R |
| 30483 | | Module Name (Low Word) | R |
| 30484 | | Module Name (High Word) Read 40483 and 40484 Response: 0x61 0x04 0x53 0x43 (SC6104) | R |
| 30485 | 40485 | Module Address Valid Range: 1 ~ 247 | R / W |
| 30486 | 40486 | Module Baud Rate See Section 2.6 Software Configuration Table | R / W |
| 30488 | 40488 | Modbus Response Delay Time (≤ 30ms) Valid Range: 0x0000 ~ 0x001E ms | R / W |
| 30489 | 40489 | Host watchdog timeout value, 0 ~ 255, in 0.1s | R / W |
| 30492 | 40492 | Host watchdog timeout count, write 0 to clear | R / W |
| 30498 | 40498 | Module Boot Up Delay Time (≤ 3000ms) Valid Range: 0x0000 ~ 0x0BB8 ms | R / W |

4.2. Function 01 - Read Coils

This function code is used to read the value at addresses 0xxxx.

Request

| Byte | Description | Value |
|---------|-------------------|--------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x01 |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 0xxxx |
| 04 – 05 | Bit Count | Number of bit (B) to read |

Response

| Byte | Description | Value |
|------------|---------------|-----------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x01 |
| 02 | Byte Count | Response data byte N = B/7 |
| 03 – (N+2) | Bit Value | Response bit data |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x81 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.3. Function 02 - Read Discrete Inputs

This function code is used to read the value at addresses 1xxxx.

Request

| Byte | Description | Value |
|---------|-------------------|--------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x02 |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 1xxxx |
| 04 – 05 | Bit Count | Number of bit (B) to read |

Response

| Byte | Description | Value |
|---------------------|---------------|-----------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x02 |
| 02 | Byte Count | Response data byte N = B/7 |
| 03 – (N +2) | Bit Value | Response bit data |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x82 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.4. Function 03 - Read Multiple Registers

This function code is used to read the value at addresses 4xxxx.

Request

| Byte | Description | Value |
|---------|-------------------|--------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x03 |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 4xxxx |
| 04 – 05 | Word Count | Number of word (W) to read |

Response

| Byte | Description | Value |
|---------------------|---------------|-----------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x03 |
| 02 | Byte Count | Response data byte N = W*2 |
| 03 – (N +2) | Word Value | Response word data |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x83 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.5. Function 04 - Read Multiple Input Registers

This function code is used to read the value at addresses 3xxxx.

Request

| Byte | Description | Value |
|---------|-------------------|--------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x04 |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 3xxxx |
| 04 – 05 | Word Count | Number of word (W) to read |

Response

| Byte | Description | Value |
|---------------------|---------------|-----------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x04 |
| 02 | Byte Count | Response data byte N = W*2 |
| 03 – (N +2) | Word Value | Response word data |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x84 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.6. Function 05 – Write Single Coil

This function code is used to write a value to addresses 0xxxx.

Request

| Byte | Description | Value |
|---------|-------------------|---|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x05 |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 0xxxx |
| 04 – 05 | Output Value | Output ON: 0xFF00 Output OFF: 0x0000 |

Response

| Byte | Description | Value |
|---------|-------------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x05 |
| 02 – 03 | Reference Address | The same as byte 02 – 03 of request |
| 04 – 05 | Output Value | The same as byte 04 – 05 of request |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x85 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.7. Function 06 – Write Single Register

This function code is used to write a value to addresses 4xxxx.

Request

| Byte | Description | Value |
|---------|-------------------|--------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x06 |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 0xxxx |
| 04 – 05 | Output Value | A word value |

Response

| Byte | Description | Value |
|---------|-------------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x06 |
| 02 – 03 | Reference Address | The same as byte 02 – 03 of request |
| 04 – 05 | Output Value | The same as byte 04 – 05 of request |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x86 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.8. Function 15 – Write Multiple Coils

This function code is used to write values to addresses 0xxxx.

Request

| Byte | Description | Value |
|------------|-------------------|--|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x0F |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 0xxxx |
| 04 – 05 | Bit Count | Number of bit (B) to write |
| 06 | Byte Count | Byte number N = B/7 |
| 07 – (N+6) | Write Data | A bit corresponds to a channel. Output ON: The bit = 1 Output OFF: The bit = 0 |

Response

| Byte | Description | Value |
|---------|-------------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x0F |
| 02 – 03 | Reference Address | The same as byte 02 – 03 of request |
| 04 – 05 | Output Value | The same as byte 04 – 05 of request |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x8F |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.9. Function 16 – Write Multiple Registers

This function code is used to write values to addresses 4xxxx.

Request

| Byte | Description | Value |
|---------------------|-------------------|--------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x10 |
| 02 – 03 | Reference Address | Refer to section 4.1 – Address 0xxxx |
| 04 – 05 | Word Count | Number of word (W) to write |
| 06 | Byte Count | Byte number N = W*2 |
| 07 – (N +6) | Write Data | Multiple word data |

Response

| Byte | Description | Value |
|---------|-------------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x10 |
| 02 – 03 | Reference Address | The same as byte 02 – 03 of request |
| 04 – 05 | Output Value | The same as byte 04 – 05 of request |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x90 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10. Function 70 – Read/Write Module Setting

This function code is used to read the configuration settings from the module or to change the settings for the module. The following sub-function codes are supported.

| Sub-function Code | Description | Section |
|--------------------------|--|----------------|
| 00(0x00) | Read the name of the module | 4.10.1 |
| 04(0x04) | Set the module address | 4.10.2 |
| 05(0x05) | Read the communication settings | 4.10.3 |
| 06(0x06) | Set the communication settings | 4.10.4 |
| 32(0x20) | Read the firmware version | 4.10.5 |
| 39(0x27) | Set the digital output power-on value | 4.10.6 |
| 40(0x28) | Read the digital output power-on value | 4.10.7 |
| 53(0x35) | Set the response delay time | 4.10.8 |
| 54(0x36) | Read the response delay time | 4.10.9 |

If the module does not support the sub-function code specified in the message, then it will respond as follows:

Error Response

| Byte | Description | Value |
|-------------|--------------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.1. Sub-function 00 – Read Module Name

This sub-function code is used to read the name of the SC-6104-W5 module.

Request

| Byte | Description | Value |
|------|-------------------|---------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x00 |

Response

| Byte | Description | Value |
|---------|-------------------|-------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x00 |
| 03 – 06 | Module Name | 0x53 0x43 0x61 0x04 (SC-6104) |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.2. Sub-function 04 – Write Module Address

This sub-function code is used to set the address of the SC-6104-W5 module.

Request

| Byte | Description | Value |
|---------|-------------------|----------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x04 |
| 03 | New Address | 1 ~ 247 |
| 04 – 06 | Reserved | 0x00 0x00 0x00 |

Response

| Byte | Description | Value |
|---------|-------------------|----------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x04 |
| 03 | New Address | 0: OK. Others: Error |
| 04 – 06 | Reserved | 0x00 0x00 0x00 |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.3. Sub-function 05 – Read Communication Setting

This sub-function code is used to read the communication protocol settings for the SC-6104-W5 module.

Request

| Byte | Description | Value |
|------|-------------------|---------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x05 |
| 03 | Reserved | 0x00 |

Response

| Byte | Description | Value |
|---------|-------------------|--|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x05 |
| 03 | Reserved | 0x00 |
| 04 | Baud Rate | Refer to section 2.6 Baud Rate Setting |
| 05 – 07 | Reserved | 0x00 |
| 08 | Mode | 0: DCON. 1: Modbus RTU |
| 09 – 10 | Reserved | 0x00 0x00 |

Note: This information is the data saved in the EEPROM and will be used for the next power-on reset. It is NOT the currently used settings

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.4. Sub-function 06 – Write Communication Setting

This sub-function code is used to configure the communication protocol for the SC-6104-W5 module.

Request

| Byte | Description | Value |
|---------|-------------------|--|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x06 |
| 03 | Reserved | 0x00 |
| 04 | Baud Rate | Refer to section 2.6 Baud Rate Setting |
| 05 – 07 | Reserved | 0x00 |
| 08 | Mode | 0: DCON. 1: Modbus RTU |
| 09 – 10 | Reserved | 0x00 0x00 |

Response

| Byte | Description | Value |
|---------|-------------------|--|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x06 |
| 03 | Reserved | 0x00 |
| 04 | Baud Rate | Refer to section 2.6 Baud Rate Setting |
| 05 – 07 | Reserved | 0x00 |
| 08 | Mode | 0: DCON. 1: Modbus RTU |
| 09 – 10 | Reserved | 0x00 0x00 |

Note: This information is the data saved in the EEPROM and will be used for the next power-on reset. It is NOT the currently used settings

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.5. Sub-function 32 – Read Firmware Version

This sub-function code is used to read the firmware version information for the SC-6104-W5 module.

Request

| Byte | Description | Value |
|------|-------------------|---------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x20 |

Response

| Byte | Description | Value |
|------|-------------------|-------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x20 |
| 03 | Major Version | 0x00 – 0xFF |
| 04 | Minor Version | 0x00 – 0xFF |
| 05 | Build Version | 0x00 – 0xFF |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.6. Sub-function 39 – Write Power-on Value

This sub-function code is used to set the power-on value for the SC-6104-W5 module.

Request

| Byte | Description | Value |
|------|-------------------|-------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x27 |
| 03 | Power-on Value | 0x00 ~ 0x0F |

Response

| Byte | Description | Value |
|------|-------------------|----------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x27 |
| 03 | Power-on Value | 0: OK. Others: Error |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.7. Sub-function 40 – Read Power-on Value

This sub-function code is used to read the power-on value for the SC-6104-W5 module.

Request

| Byte | Description | Value |
|------|-------------------|---------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x28 |

Response

| Byte | Description | Value |
|------|-------------------|-------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x28 |
| 03 | Power-on Value | 0x00 ~ 0x0F |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.8. Sub-function 53 – Set Response Delay Time

This sub-function code is used to set the Modbus RTU response delay time for the SC-6104-W5 module.

Request

| Byte | Description | Value |
|------|---------------------|------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x35 |
| 03 | Response Delay Time | 0x00 ~ 0x1E (ms) |

Response

| Byte | Description | Value |
|------|---------------------|----------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x35 |
| 03 | Response Delay Time | 0: OK. Others: Error |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |

4.10.9. Sub-function 54 – Read Response Delay Time

This sub-function code is used to read the Modbus RTU response delay time of the SC-6104-W5 module.

Request

| Byte | Description | Value |
|------|-------------------|---------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function code | 0x36 |

Response

| Byte | Description | Value |
|------|---------------------|------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0x46 |
| 02 | Sub-function Code | 0x36 |
| 03 | Response Delay Time | 0x00 ~ 0x1E (ms) |

Error Response

| Byte | Description | Value |
|------|----------------|-------------------------------------|
| 00 | Module ID | 1 ~ 247 |
| 01 | Function Code | 0xC6 |
| 02 | Exception Code | Refer to section 4 – Error Response |